

HITACHI PROGRAMMABLE AUTOMATION CONTROLLER

HX Series

APPLICATION MANUAL (Motion)
(SERVICE MANUAL)

NJI-650(X)

○ Warranty period and coverage

The warranty period is the shorter period either 18 months from the date of manufacture or 12 months from the date of installation.

However within the warranty period, the warranty will be void if the fault is due to;

- (1) Incorrect use as directed in this manual and the application manual.
- (2) Malfunction or failure of external other devices than this unit.
- (3) Attempted repair by unauthorized personnel.
- (4) Natural disasters.

The warranty is for the PLC only, any damage caused to third party equipment by malfunction of the PLC is not covered by the warranty.

○ Repair

Any examination or repair after the warranty period is not covered. And within the warranty period any repair and examination which results in information showing the fault was caused by any of the items mentioned above, the repair and examination cost are not covered. If you have any questions regarding the warranty please contact with your supplier or the local Hitachi Distributor. (Depending on failure part, examination might be impossible.)

○ Ordering parts or asking questions

When contacting us for repair, ordering parts or inquiring about other items, please have the following details ready before contacting the place of purchase.

- (1) Model
- (2) Manufacturing number (MFG.NO.)
- (3) Details of the malfunction

○ Reader of this manual

This manual is described for the following person.

- Person considering the introduction of PLC
- PLC system engineer
- Person handling PLC
- Manager after installing PLC

Warning


- (1) This manual may not be reproduced in its entirety or any portion thereof without prior consent.
- (2) The content of this document may be changed without notice.
- (3) This document has been created with utmost care. However, if errors or questionable areas are found, please contact us.


Windows®2000 / XP / 7 / 8 / 10 are registered trademarks of America and other registered countries of Microsoft Corp. of the United States.


Safety Precautions

Read this manual and related documents thoroughly before installing, operating, performing preventive maintenance or performing inspection, and be sure to use the unit correctly. Use this product after acquiring adequate knowledge of the unit, all safety information, and all cautionary information. Also, make sure this manual enters the possession of the chief person in charge of safety maintenance.

Safety caution items are classified as “Danger” and “Caution” in this document.



 **DANGER** : Cases where if handled incorrectly a dangerous circumstance may be created, resulting in possible death or severe injury.



 **CAUTION** : Cases where if handled incorrectly a dangerous circumstance may be created, resulting in possible minor to medium injury to the body, or only mechanical damage

However, depending on the circumstances, items marked with  **CAUTION** may result in major accidents.

In any case, they both contain important information, so please follow them closely.

Icons for prohibited items and required items are shown below:

 : Indicates prohibited items (items that may not be performed). For example, when open flames are prohibited,  is shown.

 : Indicates required items (items that must be performed). For example, when grounding must be performed,  is shown.

1. Installation

CAUTION

- Use this product in an environment as described in the catalog and this document.
If this product is used in an environment subject to high temperature, high humidity, excessive dust, corrosive gases, vibration or shock, it may result in electric shock, fire or malfunction.
- Perform installation according to this manual.
If installation is not performed adequately, it may result in dropping, malfunction or an operational error in the unit.
- Do not allow foreign objects such as wire chips to enter the unit.
They may become the cause of fire, malfunction or failure.

2. Wiring



REQUIRED

- Always perform grounding (FE terminal).
If grounding is not performed, there is a risk of electric shocks and malfunctions.



CAUTION

- Connect power supply that meets rating.
If a power supply that does not meet rating is connected, fire may be caused.
- The wiring operation should be performed by qualified personnel.
If wiring is performed incorrectly, it may result in fire, damage, or electric shock.

3. Precautions before using



DANGER

- Do not touch the terminals while the power is on.
There is a risk of electric shock.
- Structure the emergency stop circuit, interlock circuit, etc. outside the programmable controller (hereinafter referred to as PLC).
Damage to the equipment or accidents may occur due to failure of the PLC.
However, do not interlock the unit to external load via relay drive power supply of the relay output module.



CAUTION

- When performing program change, forced output, RUN, STOP, etc., while the unit is running, be sure to verify safety.
Damage to the equipment or accidents may occur due to operation error.
- Supply power according to the power-up order.
Damage to the equipment or accidents may occur due to malfunctions.



CAUTION

- Use power supply unit of EH-PS series for supplying electric power.




CAUTION

- Do not connect DC power supply module EH-PSD to a master power circuit. Supply a power to EH-PSD through an appropriate isolation transformer less than up to 150VA by all means.

4. Preventive maintenance

 **DANGER**

- Do not connect the \oplus , \ominus of the battery in reverse. Also, do not charge, disassemble, heat, place in fire, or short circuit the battery.
There is a risk of explosion or fire.

 **PROHIBITED**

- Do not disassemble or modify the unit.
Electric shock, malfunction or failure may result.

 **CAUTION**

- Turn off the power supply before removing or attaching module/unit.
Electric shock, malfunction or failure may result.

Revision History

No.	Description of revision	Date of revision	Manual number
1	The first edition	2017.9	NJI-650(X)

Table of Contents

Chapter 1	Introduction of SoftMotion	1-1 to 1-4
1.1	Features	1-1
1.2	Steps to Set Up	1-1
1.3	EtherCAT Communication	1-2
1.3.1	EtherCAT Communication Architecture	1-2
1.3.2	CoE Profile	1-2
1.3.3	ESI File	1-2
1.3.4	EtherCAT State Machine	1-3
Chapter 2	Precautions	2-1 to 2-10
2.1	Project Settings	2-1
2.1.1	DC Cycle Time	2-1
2.1.2	Priority of Task	2-1
2.1.3	Sync Offset	2-2
2.1.4	I/O Mapping	2-3
2.2	Restrictions of Function	2-4
2.2.1	FTP Server	2-4
2.2.2	File Transfer	2-4
2.3	Restrictions of Configuration.....	2-5
2.3.1	Modbus-TCP Master / Slave.....	2-5
2.3.2	PLC Settings (Update IO while in stop)	2-6
2.4	CPU Load	2-7
2.4.1	PLC Shell	2-7
2.4.2	CmpSchedule Library	2-8
2.5	Other Tips	2-9
2.5.1	Data Type of Axis	2-9
2.5.2	Jerk	2-9
2.5.3	EthSoftReset Command	2-9
Chapter 3	Configuration of EtherCAT and Motion Axis	3-1 to 3-24
3.1	EtherCAT Network	3-1
3.1.1	EtherCAT Master	3-1
3.1.2	Installation of ESI File	3-3
3.1.3	Slave Device	3-4
3.1.4	EtherCAT Task Cycle	3-6
3.1.5	EtherCAT Distributed Clock (Master).....	3-6
3.1.6	EtherCAT Distributed Clock (Slave).....	3-7
3.1.7	Node Address	3-7
3.1.8	Additional Settings	3-8
3.1.9	Process Data Object	3-9
3.1.10	Startup Parameters.....	3-11
3.1.11	Read/Write Object Dictionary.....	3-12
3.1.12	Programming.....	3-13
3.1.13	Wiring	3-14
3.2	Configuration of SoftMotion Axis	3-15
3.2.1	Adding SoftMotion Axis	3-15
3.2.2	Renaming SoftMotion Axis.....	3-16
3.2.3	Configuration of SoftMotion Axis.....	3-17
3.2.4	Virtual Axis	3-23

Chapter 4	Manual Operation	4-1 to 4-4
4.1	Servo-On.....	4-1
4.2	Jogging	4-4
4.3	Inching	4-4
Chapter 5	Single-Axis Control	5-1 to 5-4
5.1	Homing.....	5-1
5.2	Position Control.....	5-1
5.3	Velocity Control.....	5-3
5.4	Stop.....	5-4
Chapter 6	Multi-Axis Control	6-1 to 6-4
6.1	Cam Synchronization.....	6-1
6.1.1	Cam Table Definition	6-1
6.1.2	Sample Program	6-2
6.2	Gear Synchronization	6-3
Chapter 7	Function Blocks for Motion Control	7-1 to 7-50
7.1	State Diagram	7-1
7.2	Function Block Interface	7-2
7.3	PLCopen Part 1 for Single-Axis	7-5
7.3.1	MC_Power	7-5
7.3.2	MC_Home.....	7-6
7.3.3	MC_Stop	7-7
7.3.4	MC_Halt	7-7
7.3.5	MC_MoveAbsolute.....	7-8
7.3.6	MC_MoveRelative.....	7-9
7.3.7	MC_MoveAdditive	7-10
7.3.8	MC_MoveSuperImposed	7-11
7.3.9	MC_MoveVelocity	7-12
7.3.10	MC_PositionProfile	7-13
7.3.11	MC_VelocityProfile.....	7-13
7.3.12	MC_AccelerationProfile	7-14
7.3.13	MC_ReadActualPosition	7-15
7.3.14	MC_ReadAxisError	7-15
7.3.15	MC_ReadParameter	7-16
7.3.16	MC_ReadBoolParameter.....	7-17
7.3.17	MC_WriteParameter	7-17
7.3.18	MC_WriteBoolParameter	7-18
7.3.19	MC_ReadStatus.....	7-19
7.3.20	MC_Reset	7-20
7.4	PLCopen Part 2 for Single-Axis	7-21
7.4.1	MC_TouchProbe	7-21
7.4.2	MC_AbortTrigger.....	7-22
7.4.3	MC_DigitalCamSwitch	7-23
7.4.4	MC_ReadActualTorque	7-24
7.4.5	MC_ReadActualVelocity	7-25
7.4.6	MC_SetPosition	7-25
7.4.7	SMC_MoveContinuousAbsolute	7-26
7.4.8	SMC_MoveContinuousRelative	7-27

7.5	PLCopen Part 3 for Single-Axis	7-28
7.5.1	MC_Jog	7-28
7.5.2	SMC_Inch	7-29
7.6	PLCopen for Multi-Axis	7-30
7.6.1	MC_CamIn	7-30
7.6.2	MC_CamOut	7-32
7.6.3	MC_CamTableSelect	7-32
7.6.4	MC_GearIn	7-33
7.6.5	MC_GearInPos	7-34
7.6.6	MC_GearOut	7-35
7.6.7	MC_Phasing	7-36
7.7	Utility Function Blocks	7-37
7.7.1	SMC3_ReinitDrive	7-37
7.7.2	SMC_GetTappetValue	7-37
7.7.3	SMC_Homing	7-38
7.7.4	SMC_SetTorque	7-39
7.7.5	SMC_SetControllerMode	7-39
7.7.6	SMC_SetMovementType	7-40
7.7.7	SMC_SetRampType	7-40
7.7.8	SMC_InPosition	7-41
7.8	STRUCT	7-42
7.8.1	MC_TP_REF	7-42
7.8.2	MC_TV_REF	7-42
7.8.3	MC_TA_REF	7-42
7.8.4	SMC_TP	7-42
7.8.5	SMC_TV	7-42
7.8.6	SMC_TA	7-42
7.8.7	TRIGGER_REF	7-42
7.8.8	MC_CAMSWITCH_REF	7-42
7.8.9	MC_CAMSWITCH_TR	7-43
7.8.10	MC_CAM_ID	7-43
7.8.11	SMC_TAPPETDATA	7-43
7.8.12	SMC_CAMTAPPET	7-43
7.8.13	MC_TRACK_TR	7-43
7.9	Enumeration (ENUM)	7-44
7.9.1	MC_DIRECTION	7-44
7.9.2	MC_TAPPETMODE	7-44
7.9.3	MC_STARTMODE	7-44
7.9.4	SMC_CAMTAPPETTYPE	7-44
7.9.5	SMC_CAMTAPPETACTION	7-44
7.9.6	SMC_RAMPTYPE	7-44
7.9.7	SMC_CONTROLLER_MODE	7-45
7.9.8	SMC_HOMING_MODE	7-45
7.9.9	SMC_ERROR	7-46

Chapter 8	Visualization Template	8-1 to 8-6
-----------	------------------------	------------

8.1	Overview	8-1
8.2	Programming and Operation	8-2

Chapter 9	Trouble Shooting	9-1 to 9-8
-----------	------------------	------------

9.1	Power-up Sequence	9-1
9.2	Trouble Shooting	9-2

Appendix	Abbreviations	A-1
----------	---------------	-----

MEMO

Chapter 1 Introduction of SoftMotion

1.1 Features

HX-series CPU module (hereinafter called HX-CPU) supports SoftMotion functionality with built-in Ethernet port configured as EtherCAT master. Variety of motion controls such as single axis positioning, synchronous control with electronic cam, speed control, torque control can be performed. The commands for motion control are basically standard function blocks defined by PLCopen®*.

EtherCAT slaves of servo drives supporting CiA402 drive profile can be operated easily without users considering status word, control word, mode register and other mapping parameters.

* PLCopen is a worldwide association to standardize global standard IEC61131-3. Motion control library, safety, XML specification and other standard not defined in IEC61131-3 are defined by PLCopen.

1.2 Steps to Set Up

Following steps are required for motion control.

Create new project



Configure EtherCAT network (Chapter 3)



Configure EtherCAT slave (Chapter 3)



Configure motion parameters (Chapter 3)



Programming (Chapter 4 to 7)




Change program



Debug (Chapter 8 to 9)




Finish



1.3 EtherCAT Communication

1.3.1 EtherCAT Communication Architecture

HX-CPU SoftMotion is to access slave devices in EtherCAT network. Communication protocol for motion control is the CAN application protocol over EtherCAT (CoE), and supported profile is IEC61800-7 (CiA402). EtherCAT architecture is shown as below block diagram.



CoE support area

1.3.2 CoE Profile


2 types of communication are defined in CoE. The one is PDO (process data object) and the other is SDO (service data object). PDO is cyclic communication to object dictionary which can be mapped as PDO. SDO is non-cyclic message communication to whole the object dictionary.

PDO: From application view point, data is accessed in cyclic as variables (I/O) mapped in PDO mapping table.

SDO: From application view point, data is accessed by special function block in user program or by startup parameters (as initial values).


1.3.3 ESI File

Vendor name, device group, PDO mapping, sync manager and other parameters of EtherCAT[®] slave are defined in ESI (EtherCAT Slave Information). When ESI file is installed in configurator (HX-CODESYS), ENI file having network information is created, which will be downloaded to EtherCAT master.



1.3.4 EtherCAT State Machine

EtherCAT slaves follow ESM (EtherCAT State Machine), which is controlled by EtherCAT master. Availability of PDO and SDO are defined according to ESM.



Available communication

Status	Description	SDO	PDO
Init	Under initialization of communication. No service is available.	-	-
Pre-Operational	Only SDO is available. After initialization completed, the state goes to pre-operational mode.	✓	-
Safe-Operational	Besides SDO communication, input of PDO communication is available. If an error is found in operational mode, the state goes to safe-operational mode.	✓	✓ (input only)
Operational	Normal communication state. Input and output of PDO communication are available.	✓	✓

MEMO

Chapter 2 Precautions

If DC (Distributed Clock) is enabled, be sure to follow the instructions below. DC is a function to compensate hardware delay by sharing system clock between a master and all slaves. If slaves do not receive data from master within specified time, slaves stop operation with DC error.

2.1 Project Settings

Be sure to set following parameters according to your system configuration.

2.1.1 DC Cycle Time

Set appropriate DC cycle time. The table below shows recommended cycle time according to the number of axes, however these values are based on the minimum conditions (small user program without additional communication load such as Modbus). Tune cycle time according to your system configurations.


The number of axes	DC cycle time
1 to 4	2ms
5 to 8	4ms
9 or more	8ms

2.1.2 Priority of Task

Be sure to set 0 for the EtherCAT task (EtherCAT_Master_SoftMotion.EtherCAT.Task). If EtherCAT master device is added, it will be allocated under MainTask (priority 0) automatically. If 2 or more tasks exist, it will be allocated under the task located at the top.

POU handling motion control should be executed by EtherCAT task.

Other programs than motion control and time consuming programs should be separated from motion control and executed by lower priority task than MainTask. Set priority 5 or lower (5 to 31) to this task. In the below figure, SubTask with priority 5 is added and POU1 is assigned.



Task Cycle Time

Actual cycle time of each task can be monitored in [Task Configuration]. Double-click [Task Configuration] in device tree and choose [Monitor] tab.

Task	Status	IEC-Cycle Count	Cycle Count	Last Cycle Time (µs)	Average Cycle Time (µs)	Max. Cycle Time (µs)	Min. Cycle Time (µs)
MainTask	Valid	859	1021	2089	1692	2110	14
SubTask	Valid	172	204	9802	8317	10284	9

2.1.3 Sync Offset

Allowable jitter of EtherCAT frame for DC synchronization can be set in Sync Offset. Default value is 20%. If DC synchronization fails by big jitter, set greater value up to 50%.

The screenshot shows the configuration window for an EtherCAT Master. The window title is "EtherCAT_Master x". On the left is a sidebar with menu items: "General", "Sync Unit Assignment", "EtherCAT I/O Mapping", "Status", and "Information". The "General" tab is active. At the top right of the main area is the "EtherCAT" logo. Below the logo, there is a checked checkbox for "AutoconfigMaster/Slaves". The "EtherCAT NIC Setting" section includes: "Destination Address (MAC)" set to "FF-FF-FF-FF-FF-FF" with a checked "Broadcast" checkbox and an unchecked "Enable Redundancy" checkbox; "Source Address (MAC)" set to "00-01-02-03-04-11" with a "Browse..." button; "Network Name" set to "eth2"; and radio buttons for "Select network by MAC" (selected) and "Select network by Name". Below this are two sections: "Distributed Clock" and "Options". Under "Distributed Clock", "Cycletime" is set to "2000" μ s, "Sync Offset" is set to "20" % (highlighted with a red box), and "Sync Window Monitoring" is unchecked. Under "Options", "Use LRW instead of LWR/LRD" is unchecked, "Enable messages per task" is unchecked, and "Auto restart slaves" is checked. At the bottom, "Sync window" is set to "1" μ s.

2.1.4 I/O Mapping

There are 2 different mappings available to access external I/O or Modbus I/O. The one is that variables are directly mapped in mapping table and used in POU's. The other is that variables are declared in POS or GVL and referred from mapping table.

The secondary mentioned mapping could give extra CPU load when online change, which can lead to DC synchronous failure. If this mapping is necessary, do not map more than 200 variables to be referred. If variables over 200 are to be mapped, use direct mapping.

(1) Direct mapping

The screenshot shows the configuration for a Modbus TCP Slave. The 'Channels' table is as follows:

Variable	Mapping	Channel	Address	Type
		Channel 0	%IW0	ARRA...
		Channel ...	%IW0	WORD
test0		Bit0	%IX0.0	BOOL
test1		Bit1	%IX0.1	BOOL
test2		Bit2	%IX0.2	BOOL
test3		Bit3	%IX0.3	BOOL

Below the configuration, the PLC program 'PLC_PRG' is shown with the following code:

```

1 PROGRAM PLC_PRG
2 VAR
3 END_VAR
4

```

The ladder logic diagram shows a series of normally open contacts labeled test0, test1, test2, and test3, connected to a coil labeled DO_bit0.

(2) Declaration in POU/GVL and referred from mapping table

The screenshot shows the configuration for a Modbus TCP Slave with indirect mapping. The 'Channels' table is as follows:

Variable	Mapping	Channel	Address	Type
		Channel 0	%IW0	ARRA...
		Channel ...	%IW0	WORD
Application.PLC_PRG.test0		Bit0	%IX0.0	BOOL
Application.PLC_PRG.test1		Bit1	%IX0.1	BOOL
Application.PLC_PRG.test2		Bit2	%IX0.2	BOOL
Application.PLC_PRG.test3		Bit3	%IX0.3	BOOL

Below the configuration, the PLC program 'PLC_PRG' is shown with the following code:

```

1 PROGRAM PLC_PRG
2 VAR
3   test0: BOOL;
4   test1: BOOL;
5   test2: BOOL;
6   test3: BOOL;
7 END_VAR
8

```

The ladder logic diagram is identical to the one in the first example, showing a series of normally open contacts labeled test0, test1, test2, and test3, connected to a coil labeled DO_bit0.

2.2 Restrictions of Function


Do not use below functions while PLC is in RUN status, otherwise DC synchronous could fail.

2.2.1 FTP Server

Since FTP server could have heavy load on communication process of CPU, do not use it when PLC is in RUN status. If it is necessary to use while CPU running, use it only when drives are stopping.

2.2.2 File Transfer

Since file transfer function in [Device]-[File] could have heavy load on communication process of CPU, do not use it when PLC is in RUN status. If it is necessary to use while CPU running, use it only when drives are stopping.



2.3 Restrictions of Configuration


Follow the instruction below, otherwise DC synchronous could fail.

2.3.1 Modbus-TCP Master / Slave

Be sure to use Ethernet Adapter version 3.5.10.0 or newer. Ethernet Adapter is required when using Modbus-TCP master or slave.

Name	Vendor	Version
Miscellaneous		
Fieldbusses		
CANbus		
EtherCAT		
Ethernet Adapter		
Ethernet	3S - Smart Software Solutions GmbH	3.5.10.0

Device version can be seen in [Information] tab.




The screenshot shows the configuration window for an Ethernet device. The 'Information' tab is selected, displaying the following details:

Name:	Ethernet
Vendor:	3S - Smart Software Solutions GmbH
Groups:	Ethernet Adapter, Ethernet Adapter, Ethernet Adapter
Type:	110
ID:	0000 0002
Version:	3.5.10.0
Model Number:	-
Description:	Ethernet Link.

2.3.2 PLC Settings (Update IO while in stop)

Update IO while in stop of HX-CP1S08M is disabled as default.



CAUTION


Do not enable this parameter. otherwise drives could move rapidly when reset operation (Reset warm, Reset cold, Reset origin) because target position is reset at that time. If this parameter is to be enabled, be sure to check carefully how drives react for reset operation when the current position is not 0.

2.4 CPU Load

If CPU load exceeds 80%, CPU stops with processor overload exception (error code 25). Check the CPU load as follows and make your application program so as not to exceed 80%.

2.4.1 PLC Shell


CPU load can be checked manually with PLC shell function of HX-CODESYS. Double-click [Device], choose [PLC shell], type “plcload” in the field at the bottom, and hit [Enter] key. The current CPU load is shown.




2.4.2 CmpSchedule Library

CPU load can be taken with a special function in your application program. This could be used for warning of CPU load.

(1) Add CmpSchedule library




(2) CPU load is taken by output of FUNCTION SchedGetProcessorLoad.




Sample program

FBD/LD




ST



2.5 Other Tips

2.5.1 Data Type of Axis

Data type of axis used in motion FBs is `AXIS_REF_SM3` having more than hundreds of members.



The data of `AXIS_REF_SM3` members can be monitored however, only variables mapped in PDO can be updated basically. For example, actual position `fActPosition` is updated in realtime, but actual jerk `fActJerk` is always 0.


MC_MoveRelative_0	MC_MoveRelative			
Axis	REFERENCE TO AXI...			Reference to axis
wAxisStructID	WORD	65042		
nAxisState	SMC_AXIS_STATE	standstill		State of the axis according to the ``PLCopen..
bRegulatorOn	BOOL	TRUE		Parameter number: 1010
bDriveStart	BOOL	TRUE		Parameter number: 1011
bCommunication	BOOL	TRUE		``TRUE``: Communication OK
wCommunicationState	WORD	100		Parameter number: 1013
uiDriveInterfaceError	UINT	0		Drive interface error number
fSetPosition	LREAL	110.0000152587...		Parameter number: 1100, 1
fActPosition	LREAL	110.0000152587...		Parameter number: 1101
fSetJerk	LREAL	0		Parameter number: 1140
fActJerk	LREAL	0		Parameter number: 1141

2.5.2 Jerk

Jerk is the rate of change of acceleration.

The relation of position, velocity, acceleration and jerk are shown as follows.


The rate of change of position = Velocity
 The rate of change of velocity = Acceleration
 The rate of change of acceleration = Jerk



2.5.3 EthSoftReset Command

Function block EthSoftReset in CmpHIESLib_HX library is to soft reset Ethernet port.

HX-CPU (HX-CP1S08M) does not support this function block. If executed, xError output will be activated as follows.





EthSoftReset is to soft reset on designated Ethernet port. If Ethernet port does not work due to some reasons, it could restore by executing this function block. If this happens in motion type CPU, try to restore by reset warm or power rebooting (CPU stops by reset warm).

Chapter 3 Configuration of EtherCAT and Motion Axis


3.1 EtherCAT Network

3.1.1 EtherCAT Master


Right-click on [Device] and choose [Add Device...].
 [Add Device] window appears.
 Click [EtherCAT Master SoftMotion] and
 [Add Device] button.




Double click [EtherCAT_Master_SoftMotion (EtherCAT Master SoftMotion)] to configure Ethernet port. After communication between PC and HX-CPU configured, click [Browse...] button and choose Ethernet port for EtherCAT master.




* [Enable Redundancy] is not supported.



* Be sure to use [eth1] or [eth2] for EtherCAT master.

Click  mark at [Options] to open optional setting parameters.



Use LRW instead of LWR/LRD

Disable: Read command (LRD) and write command (LWR) are used.

Enable: Read/write command (LRW) is used.

If LRW is used, communication efficiency is higher since the packet length is shorter. Be noted some of slave devices may not support LRW command (this information is written in ESI file).

If this parameter is enabled and FMMU (Fieldbus memory management unit) of slave is customized, it is possible to communicate directly between slaves without master control. FMMU setting appears in each slave device by disabling [AutoconfigMaster/Slaves] then enabling [Show generic device configuration views] in [Tool] - [Options] – [Device editor]. Customizing FMMU is for experts only. You don't have to enable this parameter because direct communication between slaves is not used in normal operation with function block.

Enable messages per task

Enable: Variables in PDO mapping are updated by the task of POU instead of EtherCAT task. (e.g. Even if EtherCAT master is assigned to 4ms task, variable is transferred every 20ms cycle because the POU including this variable is assigned to 20ms task.)

Disable: Variables in PDO mapping are updated by EtherCAT task.

Auto restart slaves


Enable: If communication stops due to cable disconnection or other temporary reasons, communication restarts automatically.

Disable: Once communication stops, it does not restart.

3.1.2 Installation of ESI File


Install ESI file (EtherCAT Slave Information file) of your EtherCAT slave devices on HX-CODESYS. This installation is required once per PC for every slave device. If you installed before, it is not necessary to install for every new project. ESI file is provided by slave's vendor.

Choose [Tools]-[Device repository] and click [Install] button. Then new dialog appears to choose file. Click [Open] to install ESI file.





3.1.3 Slave Device

Right-click on [EtherCAT_Master_SoftMotion] and choose [Add Devices...]. Devices of ESI file installed before are listed in [Add Devices] window. Choose slave devices and click [Add Device] button.





NOTE


In case right ESI file is configured in the project and the ESI file is not registered in device repository (e.g. project file is opened in another PC than originally created), [?] sign is indicated at the icon as follows however, operation of PLC is no problem because information of ESI file is saved in the project file.



If slave devices are connected to EtherCAT network, configuration data can be read out from the network. This must be done in offline (logout) after online (login) once. Right-click on [EtherCAT_Master_SoftMotion], choose [Scan for Devices...] and click [Copy All Devices to Project]. Then connected devices will be configured under [EtherCAT Master SoftMotion].




If ESI file for connected slave is not installed, correct device name is not read out properly. In that case, obtain right ESI file from the slave vendor and install it in [Tools]-[Device Repository].




NOTE

If [Scan For Devices] is executed for two or more drives, they will be configured like a tree as below figure. In this case, SoftMotion axis (SoftMotion CiA402 Axis: refer to chapter 3.2) cannot be added except for the drive at the bottom. If you use 2 or more drives, configure manually instead of Scan For Devices.




3.1.4 EtherCAT Task Cycle

If EtherCAT Master Softmotion is added, an object to execute EtherCAT master will be automatically created under the task located to the top. Double click the task having [EtherCAT_Master_SoftMotion.EtherCAT_Task] (MainTask in case of below figure) to open configuration window.




Be sure to set the same cycle time as the cycle time of Distributed Clock to this task.



3.1.5 EtherCAT Distributed Clock (Master)

Distributed Clock, one of the features of EtherCAT, is used in motion control for synchronization between master and slaves in general. The type and enabling/disabling are configured in each slave device however, cycle time is set in master. Double click on [EtherCAT_Master_SoftMotion] and set the cycle time in [General] tab.




NOTE

- Allowable cycle time of Distributed Clock are $250\mu\text{s}$ / $500\mu\text{s}$ / 1ms / 2ms / 4ms / 8ms in general however, it is recommended to use 1 to 8ms for HX-CPU, otherwise drives do not work properly.
- Depending on the number of axes, DC synchronization could be lost. As a reference, set 2ms for 4 axes, and 4ms for 8 axes at minimum.
- If you change DC cycle time of EtherCAT, task cycle time of [EtherCAT_Master_SoftMotion.EtherCAT_Task] is automatically changed. But if you change the task cycle at first, DC cycle time of EtherCAT is not changed.
- If you add EtherCAT master device, the task cycle of EtherCAT_Master_SoftMotion.EtherCAT_Task is automatically changed to $4000\mu\text{s}$.

3.1.6 EtherCAT Distributed Clock (Slave)

Double click on a slave device and configure DC types. The contents of this drop-down menu are different in drives because this information is described in ESI file. Refer to the instruction manual of drives for further information.



3.1.7 Node Address

Two types of addresses, auto increment address and station alias, are available in EtherCAT. The default setting of HX-CODESYS is auto increment address.


Auto Increment address

Station address is automatically assigned by a master according to physical location in the network. You don't have to set addresses on slave devices.

Station Alias

Each slave has unique address. Since this address is independent from position, you don't have to modify application program if you change EtherCAT cable routing.

Enable [Optional] at [Additional] and set [Station alias] according to the slave address.





NOTE

If the station alias is enabled, [Auto restart slaves] does not work properly. If you need to enable [Auto restart slaves], use AutoInc address.


3.1.8 Additional Settings

If [Enable Expert Settings] in [Additional] is activated, [Startup checking], [Timeouts] and other expert settings appear. If [Download Expected Slot Configuration] in [Startup checking] is activated, an error message might appear depending on drives. Do not activate this parameter because it is about MDP (Modular Device Profile), which is not used in standard drives.




3.1.9 Process Data Object

In EtherCAT communication, the data called Process Data Object (PDO) is cyclically read and written. The data structure of PDO is defined in ESI file and can be configurable by users. Please refer to instruction manual of slave devices for further information.



How to change PDO mapping

(1) Deactivate the PDO mapping currently activated.



(2) The other PDO mappings are highlighted (ready to be chosen).

Select the Outputs

Name	Type	Index
<input type="checkbox"/> 16#1600 1st receive PDO Mapping		
<input type="checkbox"/> 16#1701 258th receive PDO Mappin		
Controlword	UINT	16#6040:00
Targetposition	DINT	16#607A:00
Physical output	UDINT	16#60FE:01
Touch probe function	UINT	16#60B8:00
Modes of operation	SINT	16#6060:00
<input type="checkbox"/> 16#1702 259th receive PDO Mappin		
Controlword	UINT	16#6040:00
Targetposition	DINT	16#607A:00
Profilevelocity	UDINT	16#6081:00
Physical output	UDINT	16#60FE:01
Modes of operation	SINT	16#6060:00
<input type="checkbox"/> 16#1703 260th receive PDO Mappin		
Controlword	UINT	16#6040:00
Targetposition	DINT	16#607A:00
Target velocity	DINT	16#60FF:00
Target torque	INT	16#6071:00
Physical output	UDINT	16#60FE:01
Touch probe function	UINT	16#60B8:00
Modes of operation	SINT	16#6060:00
<input type="checkbox"/> 16#1704 261th receive PDO Mappin		
Controlword	UINT	16#6040:00
Targetposition	DINT	16#607A:00
Target velocity	DINT	16#60FF:00

Select the Inputs

Name	Type	Index
<input type="checkbox"/> 16#1A00 1st transmit PDO Map		
<input checked="" type="checkbox"/> 16#1B01 258th transmit PDO M		
Error code	UINT	16#603F:00
Statusword	UINT	16#6041:00
Position actual value	DINT	16#6064:00
Torque actual value	INT	16#6077:00
Digital inputs	UDINT	16#60FD:00
Touch probe status	UINT	16#60B9:00
Touch probe positive 1 positive value	DINT	16#60BA:00
Modes of operation display	SINT	16#6061:00
<input type="checkbox"/> 16#1B02 259th transmit PDO M		
Error code	UINT	16#603F:00
Statusword	UINT	16#6041:00
Position actual value	DINT	16#6064:00
Torque actual value	INT	16#6077:00
Velocity actual value	DINT	16#606C:00
Digital inputs	UDINT	16#60FD:00
Modes of operation display	SINT	16#6061:00
<input type="checkbox"/> 16#1B03 260th transmit PDO M		
Error code	UINT	16#603F:00
Statusword	UINT	16#6041:00
Position actual value	DINT	16#6064:00
Torque actual value	INT	16#6077:00
Following error actual value	DINT	16#60F4:00
Digital inputs	UDINT	16#60FD:00

(3) Choose new PDO mapping.

Select the Outputs

Name	Type	Index
<input type="checkbox"/> 16#1600 1st receive PDO Mapping (
<input type="checkbox"/> 16#1701 258th receive PDO Mappin		
Controlword	UINT	16#6040:00
Targetposition	DINT	16#607A:00
Physical output	UDINT	16#60FE:01
Touch probe function	UINT	16#60B8:00
Modes of operation	SINT	16#6060:00
<input checked="" type="checkbox"/> 16#1702 259th receive PDO Mappin		
Controlword	UINT	16#6040:00
Targetposition	DINT	16#607A:00
Profilevelocity	UDINT	16#6081:00
Physical output	UDINT	16#60FE:01
Modes of operation	SINT	16#6060:00
<input type="checkbox"/> 16#1703 260th receive PDO Mappin		
Controlword	UINT	16#6040:00
Targetposition	DINT	16#607A:00
Target velocity	DINT	16#60FF:00
Target torque	INT	16#6071:00
Physical output	UDINT	16#60FE:01
Touch probe function	UINT	16#60B8:00
Modes of operation	SINT	16#6060:00

Select the Inputs

Name	Type	Index
<input type="checkbox"/> 16#1A00 1st transmit PDO Map		
<input checked="" type="checkbox"/> 16#1B01 258th transmit PDO M		
Error code	UINT	16#603F:00
Statusword	UINT	16#6041:00
Position actual value	DINT	16#6064:00
Torque actual value	INT	16#6077:00
Digital inputs	UDINT	16#60FD:00
Touch probe status	UINT	16#60B9:00
Touch probe positive 1 positive value	DINT	16#60BA:00
Modes of operation display	SINT	16#6061:00
<input type="checkbox"/> 16#1B02 259th transmit PDO M		
Error code	UINT	16#603F:00
Statusword	UINT	16#6041:00
Position actual value	DINT	16#6064:00
Torque actual value	INT	16#6077:00
Velocity actual value	DINT	16#606C:00
Digital inputs	UDINT	16#60FD:00
Modes of operation display	SINT	16#6061:00
<input type="checkbox"/> 16#1B03 260th transmit PDO M		
Error code	UINT	16#603F:00
Statusword	UINT	16#6041:00


PDO mapping is seen at [EtherCAT I/O Mapping] tab. Put variable names on this mapping and create application program same as standard I/Os.

3.1.10 Startup Parameters


Initial value of SDO (service data object) can be set in [Startup parameter] tab. These values are set at starting of PLC. SDO can be read and written by dedicated function blocks in application program.

How to set Startup Parameters?

(1) Click [Add] in [Startup Parameters] tab.




(2) Choose a parameter, enter a value and click [OK].




The contents of SDO parameters (object dictionary) depend on slave device. Refer to instruction manual of slave device for further information.

(3) Startup parameter is added in the list.



3.1.11 Read/Write Object Dictionary

If [Enable Expert Settings] in [Additional] is activated, [CoE Online] tab appears and values of object dictionary can be read and written in this window.



The screenshot shows the 'ADVA_EC' configuration window with the 'CoE Online' tab selected. The 'Read Objects' button is active, and the 'Auto Update' checkbox is checked. The 'Offline from ESI File' radio button is selected. The table below displays the object dictionary entries.


Index:Subindex	Name	Flags	Type	Value
16#1000:16#00	Device Type	RO	UDINT	131474
16#1001:16#00	Error register	RO	USINT	0
16#1008:16#00	Manufacturer device name	RO	STRING(4)	'ADVA'
16#1009:16#00	Manufacturer hardware version	RO	STRING(4)	'0000'
16#100A:16#00	Manufacturer software version	RO	STRING(4)	'0101'
16#1010:16#00	Store parameters	RO	USINT	1
16#1011:16#00	Restore default parameters	RO	USINT	1
16#1018:16#00	Identity object	RO	USINT	4
16#10F1:16#00	Error Settings	RO	USINT	2
16#10F3:16#00	Diagnosis History	RO	UDINT	5
16#1600:16#00	1st receive PDO Mapping	RW	USINT	0
16#1701:16#00	258th receive PDO Mapping	RO	USINT	5
16#1702:16#00	259th receive PDO Mapping	RO	USINT	5
16#1703:16#00	260th receive PDO Mapping	RO	USINT	7
16#1704:16#00	261th receive PDO Mapping	RO	USINT	10
16#1A00:16#00	1st transmit PDO Mapping	RW	USINT	0
16#1B01:16#00	258th transmit PDO Mapping	RO	USINT	8
16#1B02:16#00	259th transmit PDO Mapping	RO	USINT	7

NOTE

Negative value cannot be set in CoE Online window. If you need to write negative value, use Startup Parameters or dedicated function blocks (ETC_CO_SdoWrite, etc.).

3.1.12 Programming

I/O mapping of slave device is shown in [EtherCAT I/O Mapping] tab. Put variable names on this mapping and create application program same as standard I/Os.



Variable	Mapping	Channel	Address	Type	Defau...	Unit	Description
		Controlword	%QW0	UINT			Controlword
		Target position	%QD1	DINT			Target position
		Profile velocity	%QD2	UDINT			Profile velocity
		Physical output	%QD3	UDINT			Physical output
		Modes of operation	%QB16	SINT			Modes of operation
		Error code	%IW0	UINT			Error code
		Statusword	%IW1	UINT			Statusword
		Position actual value	%ID1	DINT			Position actual value
		Torque actual value	%IW4	INT			Torque actual value
		Digital inputs	%ID3	UDINT			Digital inputs
		Touch probe status	%IW8	UINT			Touch probe status
		Touch probe positive 1 positive value	%ID5	DINT			Touch probe positive ...
		Modes of operation display	%IB24	SINT			Modes of operation d...

In case of motion axis, state machine of CiA402 drive profile is controlled by dedicated function blocks. You don't have to create a program to control state machine by using Controlword, Statusword, Modes of operation and Modes of operation display. (variable field can be left as empty)

NOTE

- When PLC is powered up with RUN switch position in RUN, I/O refresh of EtherCAT slaves starts about a few second after I/O refresh of standard I/O started because of configuration between EtherCAT master and all slaves. If this delay is not accepted, use a special bit register "EtherCAT_Master.xConfigFinished", which turns on when EtherCAT configuration is finished. The below codes are sample program in ST language.
- Since EtherCAT communication is handled by EtherCAT_Master task, I/O refresh cycle of EtherCAT slave is delayed one cycle at maximum compared to I/O refresh cycle of external I/O in basic and expansion bases.

Sample program

Use same instance of EtherCAT master SoftMotion.

```
IF EtherCAT_Master_SoftMotion.xConfigFinished=FALSE THEN
  RETURN;
END_IF
```

Programs here (below END_IF) are not executed while this bit is FALSE.

3.1.13 Wiring

(1) Cable

Use category 5 or higher STP (Shielded Twisted Pair) cable.

(2) Network switch

Standard network switch is not allowed to use in EtherCAT network. If necessary, use dedicated EtherCAT hub such as CU1128 sold by Beckhoff.

NOTE



When a port is used for EtherCAT master, do not use this port for other Ethernet based communication such as gateway feature (communication with HX-CODESYS or HMI), Modbus-TCP or global network variable list, otherwise EtherCAT communication performance may be limited.

3.2 Configuration of SoftMotion Axis

3.2.1 Adding SoftMotion Axis


Add SoftMotion axis to EtherCAT slave drives, so as to use motion control libraries.

Right click on slave drive and choose [Add SoftMotion CiA402 Axis].




3.2.2 Renaming SoftMotion Axis


The name of SoftMotion axis can be renamed by single clicking on SoftMotion axis. Since this name is used as an instance of axis (AXIS_REF_SM3) in all the motion function blocks, shorter name would be easy to handle.



If the instance name is changed, a dialog appears to adapt automatically all references. Click [Yes] to proceed.




Then reference list appears. Click [OK] to proceed.




NOTE

If certified drive by 3S is used, the special SoftMotion axis for the drive is automatically added. If the other uncertified drive is used, you must add a generic SoftMotion axis manually. In that case, following dialog appears. Read the message and click [OK].

**NOTE**

If you delete a SoftMotion axis, slave status is failed (red triangle icon) because <Empty> slot is remained. If a SoftMotion axis is to be deleted, delete the slave device and add again.



3.2.3 Configuration of SoftMotion Axis

Double click SoftMotion axis to open configuration parameters.


[General]

No.	Name	説明	Default
1	Axis type and limits	Virtual mode: The drive will be replaced by a simulation similar to a virtual drive device.	Disabled
		Modulo: The drive turns endlessly without limiting the traversing range (e.g. belt drive)	Finite
		Finite: The drive has a fixed work area (e.g. linear drive)	
2	Software limits	Activate the option if you want to limit the position values.	Disabled
3	Modulo settings	The maximum value of the position value (unit: u). If the current position value exceeds the modulo value, the position value goes back to 0. It is possible to set a larger value than modulo value, but the maximum value of the current position data read out from drive is this modulo value.	360.0
4	Software error reaction	Drive decelerates with specified deceleration when the position exceeds the software limits.	Enabled
5	Limits for CNC	Define limit values for velocity, acceleration and deceleration. The limits are used by the library named SMC_ControlAxisBy* to detect jumps.	1e3, 1e5, 1e5
6	Position lag supervision	Define the reaction of the system after detection a lag error.	deactivated
7	Velocity ramp type	The velocity ramp type defines the velocity profile for the velocity generating one-axis and the master/slave-modules. Trapezoid: Trapezoid velocity profile (with constant acceleration in each section). Sin ² : A velocity profile as defined as sin ² function (with constant acceleration curve). Quadratic: Acceleration profile in trapezoidal form with jerk limitation. Quadratic (smooth): Like Quadratic but generates a jerk profile without jumps.	Trapezoid
8	Identification	ID: Integer identifier. Should be unique for each drive. For example, this identifier is used in the PLC log in order to identify the drive when an error occurs.	0


Velocity ramp type

Trapezoid

Velocity profile is linear since acceleration is constant.


Sin²

A velocity profile as defined by the \sin^2 function (with constant acceleration curve)




Quadratic

Acceleration profile in trapezoidal form with jerk limitation.



Quadratic (smooth)

Like Quadratic but generates a jerk profile without jump.



[Scaling/Mapping]

Drive x

General

Scaling/Mapping

Commissioning

SM_Drive_ETC_GenericDSP402: Parameters

SM_Drive_ETC_GenericDSP402: I/O Mapping

Status

Information

Scaling

Invert direction

16#10000 increments <=> motor turns 1

1 motor turns <=> gear output turns 1

1 gear output turns <=> units in application 1

Mapping

Automatic mapping

Inputs:


Cyclic object	Object number	Address	Type
status word (in.wStatusWord)	16#6041:16#00	'%IW1'	'UINT'
actual position (diActPosition)	16#6064:16#00	'%IT1'	'INT'

No.	Name	Description
1	Invert direction	The direction of rotation is reversed. The motor receives the specified values with inversed signs.
2	increments <=> motor turns	Number of increments that correspond to a given number of motor rotations. You can see the parameter in the Configuration tab of the device editor. e.g. 17-bit encoder increments :16#20000, motor turns:1 e.g. 20-bit encoder increments :16#100000, motor turns:1
3	motor turns <=> gear output turns	Number of motor rotations that correspond to a given number of gear output rotations. e.g. motor 3 turns = gear 1 turn motor turns :3, gear output turns:1
4	gear output turns <=> unis in application	Number of gear output rotations that correspond to a unit in the application. e.g. gear 1 turn = 1mm movement with ball screw gear output turns :1, unis in application:1 e.g. gear 1 turn = 0.1mm movement with ball screw gear output turns :10, unis in application:1
5	Automatic mapping	IEC parameters that affect the drive are automatically mapped to the corresponding inputs and outputs of the device.



Example 1

Servo motor
17-bit encoder
131,072 pulses/turn

Ball screw pitch: 10mm
(10mm / turn)




Gear reduction ratio: 1/5
(motor 5 turns = gear 1 turn)





In this case, if you set 10 units for distance, motor rotates 5 turns, and consequently the table of ball screw moves 10mm. (10 units equals to 10 mm)

Example 2

Servo motor
17-bit encoder
131,072 pulses/turn






Gear reduction ratio: 1/10
(motor 10 turns = gear 1 turn)



In this case, if you set 360 units for distance, motor rotates 10 turns, and consequently the turn table rotates 1 turn (360 degrees). (360 units equals to 360 degrees)

3.2.4 Virtual Axis

Virtual drives are simulated drives in software. If a virtual axis is configured as a master axis and real axes are configured as slaves, synchronous motion control can be easily realized by controlling the master axis with using cam and gear functions. Right-click on [SoftMotion General Axis Pool] and choose [Add Device...]. Then [Add Device] window appears. Click [SM_Drive_Virtual].




If this “SM_Drive_Virtual”, which can be renamed, is set to axis input (AXIS_REF_SM3) of motion function blocks, virtual drive can be controlled as same as real drives.

MEMO

Chapter 4 Manual Operation


In this chapter, it is described about how to configure and program with HX-CPU and servo drive ADV series. The parameter settings are shown as follows. (Resolution of 17-bit encoder is 131072 (16#20000))




4.1 Servo-On

The servo drive is activated (energized) by the command MC_Power.

- (1) Drag the [Box] to **Start here** and release it.




Then an undefined function block is created.



(2) Specify the function block by either of following ways.



Direct typing

Type "MC_Power" at "???" in the function block and hit [Enter] key.




Search in Input Assistant

Click [...] and search "mc_power" at [Text search] tab.




Choose in Input Assistant

Click [...] and choose "MC_Power" under SM3_Basic library in [Category] tab.



(3) New instance “MC_Power_0” is automatically assigned. Hit [Enter] key to open Auto Declare dialog. Click [OK] or hit [Enter] key to close the dialog.



The Auto Declare dialog box contains the following fields:

- Scope: VAR
- Name: MC_Power_0
- Type: MC_Power
- Object: PLC_PRG [Application]
- Initialization: (empty)
- Address: (empty)
- Flags:
 - CONSTANT
 - RETAIN
 - PERSISTENT
- Comment: (empty)

Buttons: OK, Cancel

(4) Set inputs and outputs

The screenshot shows the PLC_PRG editor with the following code:

```

1 PROGRAM PLC_PRG
2 VAR
3 MC_Power_0: MC_Power;
4 ServoOn: BOOL;
5 END_VAR

```

The object instance MC_Power_0 is shown with the following connections:

- Drive (SM_Drive_Generi) -> Axis
- TRUE -> Enable
- ServoOn -> bRegulatorOn
- TRUE -> bDriveStart


Annotations:

- Instance (name) of SoftMotion axis: Drive (SM_Drive_Generi)
- ServoOn is new boolean variable. TRUE: Servo-ON (activated) FALSE: Servo-OFF (deactivated)
- Outputs can be opened, but "???" must be deleted.

4.2 Jogging


Add MC_Power and MC_Jog as same like the last section and put inputs and outputs as below sample.

After servo-ON by setting TRUE to servoOn input, the motor rotates in forward direction with velocity 360 (u/s) and acceleration 360 (u/s²) while JOGFWD input is TRUE. If JOGBWD is TRUE, the motor rotates in backward direction. If the both JOGFWD and JOGBWD are TRUE, motor stops.



4.3 Inching


While IFWD input is TRUE, the motor rotates in forward direction with distance 10, velocity 360 (u/s) and acceleration 3600 (u/s²). While IBWD input is TRUE, the motor rotates in backward direction with same distance, velocity and acceleration. If the both IFWD and IBWD are TRUE, motor stops.



Chapter 5 Single-Axis Control

5.1 Homing

If this function block is executed, the axis performs homing according to the homing method, velocity, acceleration and other parameters configured in the drive. Those parameters can be set by startup parameters or mailbox (function block such as ETC_CO_SdoWrite, etc.) or special configuration software provided by drive's vendor.





5.2 Position Control

A sample program is introduced about MC_MoveAbsolute with absolute position.

When EXE input is TRUE, the axis goes to position 1800 [u] with velocity 500 (u/s) and acceleration 3000 (u/s²).

As soon as arrived, the axis goes back to position 0 [u] with velocity 1000 (u/s) and acceleration 3000 (u/s²).





Direction in modulo

If direction is specified as shortest or fastest, actual direction is determined according to the current position, gear reduction ratio and modulo value.

Example:

Modulo value : 360

Scaling



Name	value	Description
MC_Direction.fastest	3	Selects the direction automatically to reach the target position as fast as possible timewise. (only modulo axes)
MC_Direction.current	2	Keeps the current direction (only modulo axes)
MC_Direction.positive	1	Moves in positive direction
MC_Direction.shortest	0	Selects the direction according to the shortest distance (only modulo)
MC_Direction.negative	-1	Moves in negative direction

Following function blocks are available for position control. Refer to chapter 7 for further information.

Function Block	Name
MC_MoveAbsolute	Moves to a specified absolute position.
MC_MoveRelative	Moves to a specified relative position.
MC_MoveAdditive	Specifies relative distance additional to the most recent commanded position.
MC_MoveSuperImposed	Specifies relative distance additional to an existing motion.
SMC_MoveContinuousAbsolute	Moves to a specified absolute position ending with the specified velocity.
SMC_MoveContinuousRelative	Moves to a specified relative position ending with the specified velocity.
MC_PositionProfile	Moves according to time-position locked motion profile.

5.3 Velocity Control


Velocity control is to specify velocity, acceleration and jerk without specifying target position. The function block for velocity control is MC_MoveVelocity.

Change velocity

Velocity, acceleration and direction can be changed while movement. In order to apply new parameters, rising edge must be input to [Execute] input. Alternatively another instance of MC_MoveVelocity can be executed. In that case, originally executed MC_MoveVelocity is aborted, which results in CommandAborted output TRUE.

Velocity Control → Switching to Position Control

It is possible to switch from velocity control to position control while movement. If MV_exe is TRUE, the axis rotates with constant velocity 500 (u/s). If MC_MoveRelative is executed while the axis is in constant movement, the axis moves, decelerates and stops with specified distance (360u) and deceleration (1000 u/s). MC_MoveVelocity is aborted with CommandAborted output TRUE.



5.4 Stop


The usage of MC_Halt and MC_Stop are to decelerate and stop motion for both, but there are some differences as follows.

MC_Halt

MC_Halt is used to stop the axis under normal operation conditions. Even the axis is in deceleration by MC_Halt command, the next command can be issued and effective.

MC_Stop

MC_Stop is primarily intended for emergency stop functionality or exceptional situations. As long as “Execute” input is TRUE, the axis remains in the state “Stopping” and may not be executing any other motion command. If “Execute” input is FALSE, the axis goes to ‘Standstill’ status.




Chapter 6 Multi-Axis Control


6.1 Cam Synchronization

6.1.1 Cam Table Definition


Right click on [Application] and choose [Add Object]-[Cam table...].




New cam table is created. The horizontal axis is the position of the master, and the vertical axes are position, velocity, acceleration and jerk of the slave for each. Graphic editor can be edited directly with mouse dragging. In addition, it is possible to specify with numeric data in [cam table] tab. Graphic data and numeric data are related dynamically.




For example, in case below cam is defined, master and slave axis rotate as follows.



Master




Slave




6.1.2 Sample Program

The minimum configuration for cam is shown as below. “CamTable” input of MC_CamTableSelect must be same name as cam table’s name under the device tree. Connect “CamTableID” output of MC_CamTable Select to “CamTableSelectID” input of MC_CamIn.



6.2 Gear Synchronization

A sample program of gearing is shown as below. When “s1” input is TRUE, the slave axis (Drive_B) rotates according to the master axis (Drive_A) with gear ratio [2:1]. If “s1” input is FALSE, the slave axis stops.



Following function blocks are available for synchronous control. Refer to chapter 7 for further information.


Function Block	Name
MC_CamIn	Engages the CAM
MC_CamOut	Disengages the slave axis from the master axis
MC_CamTableSelect	Selects the CAM table
MC_GearIn	Commands a ratio between the velocity of the slave and master axis
MC_GearInPos	Commands a ratio between the position of the slave and master axes from the synchronization point onwards.
MC_GearOut	Disengages the slave axis from the master axis.
MC_Phasing	Creates an phase shift in the master position of a slave axis.

MEMO

Chapter 7 Function Blocks for Motion Control

7.1 State Diagram

The following diagram normatively defines the behavior of the axis at a high level when multiple motion control function blocks are simultaneously activated. The axis is always in one of the defined states. Arrows within the state diagram show the possible state transitions between the states. State transitions due to an issued command are shown by full arrows. Dashed arrows are used for state transitions that occur when a command of an axis corresponding motion state are listed above the states. These motion commands may also be issued when the axis is already in the according motion state.



- *1 From any state. An error in the axis occurred.
- *2 From any state. MC_Power.Enable=FALSE and there is no error in the axis
- *3 MC_Reset AND MC_Power.Status=FALSE
- *4 MC_Reset AND MC_Power.Status=TRUE AND MC_Power.Enable=TRUE AND MC_Power.bRegulator =TRUE
- *5 MC_Power.Enable=TRUE AND MC_Power.bRegulator =TRUE AND MC_Power.Status=TRUE
- *6 MC_Stop.Done=TRUE AND MC_Stop.Execute=FALSE

NOTE

The state behavior is different from the diagram defined by PLCopen for some function blocks.

- After MC_PositionProfile done, the state is in [Discrete Motion] instead of [Standstill].
- While MC_VelocityProfile and MC_AccelerationProfile, the state is [Discrete Motion] instead of [Continuous Motion]

7.2 Function Block Interface


General rules of function block interface are described as follows.

Input parameters	<p>With 'Execute':</p> <p>The parameters are used with the rising edge of the 'Execute' input. To modify any parameter it is necessary to change the input parameter(s) and to trigger the 'Execute' input again.</p> <p>With 'Enable':</p> <p>The parameters are used with the rising edge of the enable input and can be modified continuously.</p>
Missing input parameters	<p>If any parameter of a function block input is missing ("open") then the value from the previous invocation of this instance will be used. In the first invocation the initial value is applied.</p>
Acceleration, Deceleration and Jerk inputs	<p>If the input 'Acceleration', 'Deceleration' or 'Jerk' is set to 0 or open, 'Error' output of the function block is TRUE.</p> <p>If velocity ramp type is 'Trapezoid' or 'Sin²', 'Jerk' input can be 0. However, if velocity ramp type is 'Quadratic' or 'Quadratic (smooth)', 'Jerk' input must not be zero, otherwise 'Error' output of the function block is TRUE.</p>
Output exclusivity	<p>With 'Execute':</p> <p>The outputs 'Busy', 'Done', 'Error' and 'CommandAborted' are mutually exclusive: only one of them can be TRUE on one FB. If 'Execute' is TRUE, one of these outputs has to be TRUE.</p> <p>With 'Enable':</p> <p>The outputs 'Valid' and 'Error' are mutually exclusive: only one of them can be TRUE on one FB.</p>
Output status	<p>With 'Execute':</p> <p>The 'Done', 'Error', 'ErrorID' and 'CommandAborted' outputs are reset with the falling edge of 'Execute'. However the falling edge of 'Execute' does not stop or even influence the execution of the actual FB. It must be guaranteed that the corresponding outputs are set for at least one cycle if the situation occurs, even if execute was reset before the FB completed.</p> <p>If an instance of a FB receives a new execute before it finished (as a series of commands on the same instance), the FB won't return any feedback, like 'Done' or 'CommandAborted', for the previous action.</p> <p>With 'Enable':</p> <p>The 'Valid', 'Enabled', 'Busy', 'Error' and 'ErrorID' outputs are reset with the falling edge of 'Enable' as soon as possible.</p>
Behaviour of Done output	<p>The 'Done' output is set when the commanded action has been completed successfully.</p> <p>With multiple Function Blocks working on the same axis in a sequence, the following applies: when one movement on an axis is interrupted with another movement on the same axis without having reached the final goal, 'Done' of the first FB will not be set.</p>
Behaviour of Busy output	<p>With 'Execute':</p> <p>Every FB can have an output 'Busy', reflecting that the FB is not finished and new output values can be expected. 'Busy' is SET at the rising edge of 'Execute' and RESET when one of the outputs 'Done', 'Aborted', or 'Error' is set.</p> <p>With 'Enable':</p> <p>Every FB can have an output 'Busy', reflecting that the FB is working and new output values can be expected. 'Busy' is SET at the rising edge of 'Enable' and stays SET as long as the FB is performing any action.</p> <p>It is recommended that the FB should be kept in the active loop of the application program for at least as long as 'Busy' is true, because the outputs may still change.</p>


<p>Behavior of InVelocity, InGear, InTorque and InSync</p>	<p>The outputs 'InVelocity', 'InGear', 'InTorque', and 'InSync' (from now on referred to as 'Inxxx') have a different behavior than the 'Done' output.</p> <p>As long as the FB is Active, 'Inxxx' is SET when the set value equals the commanded value, and will be RESET when at a later time they are unequal. For example, the InVelocity output is SET when the set velocity is equal to the commanded velocity. This is similar for 'InGear', 'InTorque', and 'InSync' outputs in the applicable FBs.</p> <p>'Inxxx' is updated even if 'Execute' is low as long as the FB has control of the axis ('Active' and 'Busy' are SET).</p> <p>The behavior of 'Inxxx' directly after 'Execute' is SET again while the condition of 'Inxxx' is already met, is implementation specific.</p> <p>'Inxxx' definition does not refer to the actual axis value, but must refer to the internal instantaneous setpoint.</p>
<p>Behavior of CommandAborted</p>	<p>'CommandAborted' is set, when a commanded motion is interrupted by another motion command. The reset-behavior of 'CommandAborted' is like that of 'Done'. When 'CommandAborted' occurs, the other output-signals such as 'InVelocity' are reset.</p>
<p>Enable and Valid</p>	<p>The 'Enable' input is coupled to a 'Valid' output. 'Enable' is level sensitive, and 'Valid' shows that a valid set of outputs is available at the FB.</p> <p>The 'Valid' output is TRUE as long as a valid output value is available and the 'Enable' input is TRUE. The relevant output value can be refreshed as long as the input 'Enable' is TRUE.</p> <p>If there is a FB error, the output is not valid ('Valid' set to FALSE). When the error condition disappears, the values will reappear and 'Valid' output will be set again.</p>
<p>Position, Distance</p>	<p>'Position' is a value defined within a coordinate system. 'Distance' is a relative measure related to technical units. 'Distance' is the difference between two positions.</p>
<p>Sign rules</p>	<p>The 'Acceleration', 'Deceleration' and 'Jerk' are always positive values. 'Velocity', 'Position' and 'Distance' can be both positive and negative.</p>

The behavior of FB with 'Execute' input and 'Done' output

Without error




With Execute input keeping TRUE




With rising edge of Execute input

With error




With Execute input keeping TRUE




With rising edge of Execute input

Command aborted




With Execute input keeping TRUE



With rising edge of Execute input

7.3 PLCopen Part 1 for Single-Axis

7.3.1 MC_Power

Name		MC_Power	Type: FB
This FB controls the power stage (On or Off)			
			
Name	Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	Enable	BOOL	TRUE: Enables the execution of the FB.
	bRegulatorOn	BOOL	TRUE: Enables the power stage. FALSE: Disables the power stage.
	bDriveStart	BOOL	TRUE: Disables the quickstop mechanism. FALSE: Enables the quickstop mechanism.
OUT	Status	BOOL	TRUE: Axis is ready to move.
	bRegulatorRealState	BOOL	TRUE: The power stage has been switched on.
	bDriveStartRealState	BOOL	TRUE: Drive is not blocked by the quickstop mechanism.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification

NOTE

When MC_Power is executed, there is a momentary 'Stopping' status (50 to 100ms) between 'Disabled' and 'Standstill', which can be seen with MC_ReadStatus. Although it is not described in the state diagram in page 7-1, this is expected behavior.


7.3.2 MC_Home

Name		MC_Home		Type: FB
This FB commands the axis to perform the search home sequence according to the drive. (controlled by the drive)				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Position	BOOL	Absolute position when the reference signal is detected.	
OUT	Done	BOOL	TRUE: Reference known and set successfully.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


NOTE

If a value other than 0 is set to 'Position' input, the sign of the current position might be inverted depending on drives. If inverted, set a right value with MC_SetPosition.

7.3.3 MC_Stop

Name		MC_Stop		Type: FB
This FB commands a controlled motion stop and transfers the axis to the state 'Stopping'. It aborts any ongoing Function Block execution. While the axis is in state 'Stopping', no other FB can perform any motion on the same axis.				
				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Deceleration	LREAL	Value of the 'deceleration' (u/s^2) (positive value)	
	Jerk	LREAL	Value of the 'Jerk' (u/s^3) (positive value)	
OUT	Done	BOOL	TRUE: Zero velocity reached.	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

7.3.4 MC_Halt

Name		MC_Halt		Type: FB
This FB commands a controlled motion stop. It is possible to set another motion command during deceleration of the axis, which will abort the MC_Halt and will be executed immediately.				
				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Deceleration	LREAL	Value of the 'deceleration' (u/s^2) (positive value)	
	Jerk	LREAL	Value of the 'Jerk' (u/s^3) (positive value)	
OUT	Done	BOOL	TRUE: Zero velocity reached.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


7.3.5 MC_MoveAbsolute

Name		MC_MoveAbsolute	Type: FB
This FB commands a controlled motion to a specified absolute position.			
<p>The diagram shows a rectangular function block titled "MC_MoveAbsolute". On the left side, there are eight input lines with labels: "Axis" (type <i>AXIS_REF_SM3</i>), "Execute" (type <i>BOOL</i>), "Position" (type <i>LREAL</i>), "Velocity" (type <i>LREAL</i>), "Acceleration" (type <i>LREAL</i>), "Deceleration" (type <i>LREAL</i>), "Jerk" (type <i>LREAL</i>), and "Direction" (type <i>MC_Direction</i>). On the right side, there are five output lines with labels: "Done" (type <i>BOOL</i>), "Busy" (type <i>BOOL</i>), "CommandAborted" (type <i>BOOL</i>), "Error" (type <i>BOOL</i>), and "ErrorID" (type <i>SMC_ERROR</i>).</p>			
Name		Type	Description
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	Execute	BOOL	Starts the execution of the FB at rising edge.
	Position	LREAL	Target position [u] (positive or negative)
	Velocity	LREAL	Maximum velocity [u/s] (positive)
	Acceleration	LREAL	Acceleration [u/s ²] (positive)
	Deceleration	LREAL	Deceleration [u/s ²] (positive)
	Jerk	LREAL	Jerk [u/s ³] (positive)
	Direction	MC_Direction	fastest (3), current (2), positive (1), shortest (0), negative (-1) (Refer to section 7.9 Enumeration)
OUT	Done	BOOL	TRUE: End position has been achieved.
	Busy	BOOL	TRUE: The FB is in operation.
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification


MC_DIRECTION (ENUM)

Name	Value	Description
fastest	3	Selects the direction automatically in order to reach the target position as fast as possible (only modulo axes).
current	2	Keeps the current direction to reach the target (only modulo axes).
positive	1	Moves in positive direction.
shortest	0	Selects the direction according to the shortest distance (only modulo axes).
negative	-1	Moves in negative direction.


7.3.6 MC_MoveRelative

Name		MC_MoveRelative		Type: FB
This FB commands a controlled motion to a specified distance relative to the set position.				
 <p>The diagram shows a rectangular block titled "MC_MoveRelative". On the left side, there are seven input lines with labels: "Axis AXIS_REF_SM3", "Execute BOOL", "Distance LREAL", "Velocity LREAL", "Acceleration LREAL", "Deceleration LREAL", and "Jerk LREAL". On the right side, there are five output lines with labels: "BOOL Done", "BOOL Busy", "BOOL CommandAborted", "BOOL Error", and "SMC_ERROR ErrorID".</p>				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Distance	LREAL	Relative distance [u] (positive or negative)	
	Velocity	LREAL	Maximum velocity [u/s] (positive)	
	Acceleration	LREAL	Acceleration [u/s ²] (positive)	
	Deceleration	LREAL	Deceleration [u/s ²] (positive)	
	Jerk	LREAL	Jerk [u/s ³] (positive)	
OUT	Done	BOOL	TRUE: Distance has been achieved.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


7.3.7 MC_MoveAdditive

Name		MC_MoveAdditive		Type: FB
This FB commands a controlled motion of a specified relative distance additional to the most recent commanded position in the axis state 'DiscreteMotion'.				
 <p>The diagram shows a rectangular function block titled 'MC_MoveAdditive'. On the left side, there are seven input lines: 'Axis' (type <i>AXIS_REF_SM3</i>), 'Execute' (type <i>BOOL</i>), 'Distance' (type <i>LREAL</i>), 'Velocity' (type <i>LREAL</i>), 'Acceleration' (type <i>LREAL</i>), 'Deceleration' (type <i>LREAL</i>), and 'Jerk' (type <i>LREAL</i>). On the right side, there are five output lines: 'Done' (type <i>BOOL</i>), 'Busy' (type <i>BOOL</i>), 'CommandAborted' (type <i>BOOL</i>), 'Error' (type <i>BOOL</i>), and 'ErrorID' (type <i>SMC_ERROR</i>).</p>				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Distance	LREAL	Relative distance [u] (positive or negative)	
	Velocity	LREAL	Maximum velocity [u/s] (positive)	
	Acceleration	LREAL	Acceleration [u/s ²] (positive)	
	Deceleration	LREAL	Deceleration [u/s ²] (positive)	
	Jerk	LREAL	Jerk [u/s ³] (positive)	
OUT	Done	BOOL	TRUE: Distance has been achieved.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

7.3.8 MC_MoveSuperImposed

Name		MC_MoveSuperImposed		Type: FB
This FB commands a controlled motion of a specified relative distance additional to an existing motion. The existing Motion is not interrupted, but is superimposed by the additional motion.				
 <p>The diagram shows a rectangular function block titled "MC_MoveSuperImposed". On the left side, there are seven input lines: "Axis" (type <i>AXIS_REF_SM3</i>), "Execute" (type <i>BOOL</i>), "Distance" (type <i>LREAL</i>), "VelocityDiff" (type <i>LREAL</i>), "Acceleration" (type <i>LREAL</i>), "Deceleration" (type <i>LREAL</i>), and "Jerk" (type <i>LREAL</i>). On the right side, there are five output lines: "Done" (type <i>BOOL</i>), "Busy" (type <i>BOOL</i>), "CommandAborted" (type <i>BOOL</i>), "Error" (type <i>BOOL</i>), and "ErrorID" (type <i>SMC_ERROR</i>).</p>				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Distance	LREAL	Additional distance that is to be superimposed [u] (positive or negative)	
	VelocityDiff	LREAL	Maximum velocity [u/s] (positive)	
	Acceleration	LREAL	Acceleration [u/s ²] (positive)	
	Deceleration	LREAL	Deceleration [u/s ²] (positive)	
	Jerk	LREAL	Jerk [u/s ³] (positive)	
OUT	Done	BOOL	TRUE: Distance is reached.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


7.3.9 MC_MoveVelocity

Name		MC_MoveVelocity		Type: FB
This FB commands a never ending controlled motion at a specified velocity.				
 <p>The diagram shows a rectangular block labeled 'MC_MoveVelocity'. On the left side, there are seven input lines: 'Axis' (type <i>AXIS_REF_SM3</i>), 'Execute' (type <i>BOOL</i>), 'Velocity' (type <i>LREAL</i>), 'Acceleration' (type <i>LREAL</i>), 'Deceleration' (type <i>LREAL</i>), 'Jerk' (type <i>LREAL</i>), and 'Direction' (type <i>MC_Direction</i>). On the right side, there are five output lines: 'InVelocity' (type <i>BOOL</i>), 'Busy' (type <i>BOOL</i>), 'CommandAborted' (type <i>BOOL</i>), 'Error' (type <i>BOOL</i>), and 'ErrorID' (type <i>SMC_ERROR</i>).</p>				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Velocity	LREAL	Maximum velocity [u/s] (positive)	
	Acceleration	LREAL	Acceleration [u/s ²] (positive)	
	Deceleration	LREAL	Deceleration [u/s ²] (positive)	
	Jerk	LREAL	Jerk [u/s ³] (positive)	
	Direction	MC_Direction	fastest (3), current (2), positive (1), shortest (0), negative (-1) (Refer to section 7.9 Enumeration)	
OUT	InVelocity	BOOL	TRUE: The set velocity has been reached for the first time.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


NOTE

This FB is used for speed control. However, the drives are controlled by position based control instead of speed based control internally. For this reason, 'Modes of operation' (0x6060) and Modes of operation display' (0x6061) in the object dictionary are both '8' (cyclic synchronous position mode) instead of '9' (cyclic synchronous velocity mode).


7.3.10 MC_PositionProfile

Name		MC_PositionProfile		Type: FB
This FB commands a time-position locked motion profile.				
 <p>The diagram shows the MC_PositionProfile function block with the following connections:</p> <ul style="list-style-type: none"> Inputs: Axis (AXIS_REF_SM3), TimePosition (MC_TP_REF), Execute (BOOL), ArraySize (INT), PositionScale (LREAL), Offset (LREAL). Outputs: Done (BOOL), Busy (BOOL), CommandAborted (BOOL), Error (BOOL), ErrorID (SMC_ERROR). 				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
	TimePosition	MC_TP_REF	Reference to time-position description	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	ArraySize	INT	The number of time-position profiles.	
	PositionScale	LREAL	Overall position scaling factor (initial value: 1)	
	Offset	LREAL	Overall offset for profile [u]	
OUT	Done	BOOL	The profile has been completed.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


7.3.11 MC_VelocityProfile

Name		MC_VelocityProfile		Type: FB
This FB commands a time-velocity locked motion profile.				
 <p>The diagram shows the MC_VelocityProfile function block with the following connections:</p> <ul style="list-style-type: none"> Inputs: Axis (AXIS_REF_SM3), TimeVelocity (MC_TV_REF), Execute (BOOL), ArraySize (INT), VelocityScale (LREAL), Offset (LREAL). Outputs: Done (BOOL), Busy (BOOL), CommandAborted (BOOL), Error (BOOL), ErrorID (SMC_ERROR). 				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
	TimeVelocity	MC_TV_REF	Reference to time-velocity description	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	ArraySize	INT	The number of time-velocity profiles.	
	VelocityScale	LREAL	Overall velocity scaling factor (initial value: 1)	
	Offset	LREAL	Overall offset for profile [u]	
OUT	Done	BOOL	The profile has been completed.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


7.3.12 MC_AccelerationProfile

Name		MC_AccelerationProfile		Type: FB
This FB commands a time-acceleration locked motion profile.				
 <p style="text-align: center;">MC_AccelerationProfile</p> <ul style="list-style-type: none"> — Axis <i>AXIS_REF_SM3</i> <i>BOOL</i> Done — TimeAcceleration <i>MC_TA_REF</i> <i>BOOL</i> Busy — Execute <i>BOOL</i> <i>BOOL</i> CommandAborted — ArraySize <i>INT</i> <i>BOOL</i> Error — AccelerationScale <i>LREAL</i> <i>SMC_ERROR</i> ErrorID — Offset <i>LREAL</i> 				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
	TimeAcceleration	MC_TA_REF	Reference to time-acceleration description	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	ArraySize	INT	The number of time-acceleration profiles.	
	AccelerationScale	LREAL	Overall acceleration scaling factor (initial value: 1)	
	Offset	LREAL	Overall offset for profile [u]	
OUT	Done	BOOL	The profile has been completed.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


7.3.13 MC_ReadActualPosition

Name		MC_ReadActualPosition	Type: FB
This FB returns the actual position.			
			
Name		Type	Description
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	Enable	BOOL	TRUE: Enables the execution of the FB.
OUT	Valid	BOOL	TRUE: A valid output is available.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification
	Position	LREAL	New absolute position [u]

7.3.14 MC_ReadAxisError

Name		MC_ReadAxisError	Type: FB
This FB presents general axis errors not relating to the function blocks.			
			
Name		Type	Description
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	Enable	BOOL	TRUE: Enables the execution of the FB.
OUT	Valid	BOOL	TRUE: A valid output is available.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification
	AxisError	BOOL	TRUE: Axis error has occurred.
	AxisErrorID	DWORD	Vendor specific identification of the axis error.
	SWEndSwitchActive	BOOL	TRUE: Software limits are exceeded.

7.3.15 MC_ReadParameter

Name	MC_ReadParameter		Type: FB
This FB returns the value of a vendor specific parameter with data type LREAL.			
			
Name	Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	Enable	BOOL	TRUE: Enables the execution of the FB.
	ParameterNumber	DINT	Number of the parameter (see the table below)
OUT	Valid	BOOL	TRUE: A valid output is available.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification
	Value	LREAL	Value of the parameter specified in input 'ParameterNumber'

PN	Name	Type	B/E	R/W	Description
1	CommandedPosition	REAL	B	R	Commanded position
2	SWLimitPos	REAL	E	R/W	Positive software limit switch position
3	SWLimitNeg	REAL	E	R/W	Negative software limit switch position
4	EnableLimitPos	BOOL	E	R/W	Enable positive software limit switch
5	EnableLimitNeg	BOOL	E	R/W	Enable negative software limit switch
6	EnablePosLagMonitoring	BOOL	E	R/W	Enable monitoring of position lag
7	MaxPositionLag	REAL	E	R/W	Maximal position lag
8	MaxVelocitySystem	REAL	E	R	Maximal allowed velocity of the axis in the motion system
9	MaxVelocityAppl	REAL	B	R/W	Maximal allowed velocity of the axis in the application
10	ActualVelocity	REAL	B	R	Actual velocity
11	CommandedVelocity	REAL	B	R	Commanded velocity
12	MaxAccelerationSystem	REAL	E	R	Maximal allowed acceleration of the axis in the motion system
13	MaxAccelerationAppl	REAL	E	R/W	Maximal allowed acceleration of the axis in the application
14	MaxDecelerationSystem	REAL	E	R	Maximal allowed deceleration of the axis in the motion system
15	MaxDecelerationAppl	REAL	E	R/W	Maximal allowed deceleration of the axis in the application
16	MaxJerkSystem	REAL	E	R	Maximal allowed jerk of the axis in the motion system
17	MaxJerkAppl	REAL	E	R/W	Maximal allowed jerk of the axis in the application

PN: Parameter Number

B: Basic E: Expanded

R: Read only R/W: Read and Write


7.3.16 MC_ReadBoolParameter

Name		MC_ReadBoolParameter		Type: FB
This FB returns the value of a vendor specific parameter with data type BOOL.				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Enable	BOOL	TRUE: Enables the execution of the FB.	
	ParameterNumber	DINT	Number of the parameter (see the table in 7.3.15)	
OUT	Valid	BOOL	TRUE: A valid output is available.	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	
	Value	BOOL	Value of the parameter specified in input 'ParameterNumber'	

7.3.17 MC_WriteParameter

Name		MC_WriteParameter		Type: FB
This FB modifies the value of a vendor specific parameter with data type LREAL.				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	ParameterNumber	DINT	Number of the parameter (see the table in 7.3.15)	
	Value	LREAL	New value of the specified parameter	
OUT	Done	BOOL	TRUE: Parameter successfully written	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

7.3.18 MC_WriteBoolParameter

Name		MC_WriteBoolParameter		Type: FB
This FB modifies the value of a vendor specific parameter with data type BOOL.				
				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	ParameterNumber	DINT	Number of the parameter (see the table in 7.3.15)	
	Value	BOOL	New value of the specified parameter	
OUT	Done	BOOL	TRUE: Parameter successfully written	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


7.3.19 MC_ReadStatus

Name		MC_ReadStatus		Type: FB
This FB returns in details the status of the state diagram of the selected axis.				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Enable	BOOL	TRUE: Enables the execution of the FB.	
OUT	Valid	BOOL	TRUE: A valid output is available.	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	
	Disabled	BOOL	TRUE: Disabled (see 7.1 State diagram)	
	Errorstop	BOOL	TRUE: Errorstop (see 7.1 State diagram)	
	Stopping	BOOL	TRUE: Stopping (see 7.1 State diagram)	
	StandStill	BOOL	TRUE: StandStill (see 7.1 State diagram)	
	DiscreteMotion	BOOL	TRUE: DiscreteMotion (see 7.1 State diagram)	
	ContinuousMotion	BOOL	TRUE: ContinuousMotion (see 7.1 State diagram)	
	SynchronizedMotion	BOOL	TRUE: SynchronizedMotion (see 7.1 State diagram)	
	Homing	BOOL	TRUE: Homing (see 7.1 State diagram)	
	ConstantVelocity	BOOL	TRUE: Motor moves with constant velocity.	
	Accelerating	BOOL	TRUE: Motor moves with increasing velocity.	
	Decelerating	BOOL	TRUE: Motor moves with decreasing velocity.	
FBErrorOccurred	BOOL	TRUE: FB error has occurred.		

7.3.20 MC_Reset

Name	MC_Reset	Type: FB
------	----------	----------


This FB makes the transition from the state 'ErrorStop' to 'Standstill' or 'Disabled' by resetting all internal axis-related errors.



Name		Type	Description
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	Execute	BOOL	Starts the execution of the FB at rising edge.
OUT	Done	BOOL	TRUE: Reset has been executed.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification

7.4 PLCopen Part 2 for Single-Axis

7.4.1 MC_TouchProbe

Name		MC_TouchProbe	Type: FB
This FB is used to record an axis position at a trigger event.			
 <p>The diagram shows a rectangular function block labeled MC_TouchProbe. On the left side, there are four input lines: <i>Axis</i> (type <i>AXIS_REF_SM3</i>), <i>TriggerInput</i> (type <i>TRIGGER_REF</i>), <i>Execute</i> (type <i>BOOL</i>), and <i>WindowOnly</i> (type <i>BOOL</i>). On the right side, there are six output lines: <i>Done</i> (type <i>BOOL</i>), <i>Busy</i> (type <i>BOOL</i>), <i>Error</i> (type <i>BOOL</i>), <i>ErrorID</i> (type <i>SMC_ERROR</i>), <i>RecordedPosition</i> (type <i>LREAL</i>), and <i>CommandAborted</i> (type <i>BOOL</i>).</p>			
Name	Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
	TriggerInput	TRIGGER_REF	Reference to trigger signal source
IN	Execute	BOOL	Starts the execution of the FB at rising edge.
	WindowOnly	BOOL	TRUE: Trigger events will be accepted only within the specified window.
	FirstPosition	LREAL	Start position from whereon (in positive direction) trigger events will be accepted [u].
	LastPosition	LREAL	End position up to which trigger events will be accepted [u].
OUT	Done	BOOL	TRUE: Trigger event has been recorded.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification
	RecordedPosition	LREAL	Position, where trigger event has occurred [u].
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.

7.4.2 MC_AbortTrigger

Name		MC_AbortTrigger		Type: FB
This FB is used to abort function block which are connected to trigger events.				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
	TriggerInput	TRIGGER_REF	Reference to trigger signal source	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
OUT	Done	BOOL	TRUE: Latching has been aborted successfully.	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

NOTE

MC_AbortTrigger might not work depending on drives. Possible countermeasure in this case could be to set parameter directly to drives.

7.4.3 MC_DigitalCamSwitch

Name	MC_DigitalCamSwitch		Type: FB
This FB is the analogy to switches on a motor shaft: it commands a group of discrete output bits to switch in analogy to a set of mechanical am controlled switches connected to an axis.			
<p style="text-align: center;">MC_DigitalCamSwitch</p> <ul style="list-style-type: none"> — Axis <i>AXIS_REF_SM3</i> <i>BOOL</i> InOperation — Switches <i>MC_CAMSWITCH_REF</i> <i>BOOL</i> Busy — Outputs <i>MC_OUTPUT_REF</i> <i>BOOL</i> Error — TrackOptions <i>MC_TRACK_REF</i> <i>SMC_ERROR</i> ErrorID — Enable <i>BOOL</i> — EnableMask <i>DWORD</i> — TappetMode <i>MC_TAPPETMODE</i> 			
Name	Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
	Switches	MC_CAMSWITCH_REF	Reference to switching actions
	Outputs	MC_OUTPUT_REF	Reference to signal outputs that are directly related to the referenced tracks. (ARRAY [1..32] OF BOOL)
	TrackOptions	MC_TRACK_REF	Reference to structure containing track related properties, e.g. the on/off compensations per output/track. (ARRAY [1..32] OF MC_TRACK_TR)
IN	Enable	BOOL	TRUE: Enables the execution of the FB.
	EnableMask	DWORD	32 bits of BOOL enabling the different tracks. Least significant data is related to the lowest TrackNumber. (initial value: 16#FFFFFFFF)
	TappetMode	MC_TAPPETMODE	ENUM
OUT	InOperation	BOOL	TRUE: Commanded tracks have been enabled.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification

MC_CAMSWITCH_REF (STRUCT)

Name	Type	Initial	Description
NoOfSwitches	BYTE	0	Number of switch positions
CamSwitchPtr	POINTER TO MC_CAMSWITCH_TR	0	Address of MC_CAMSWITCH_TR

MC_CAMSWITCH_TR (STRUCT)

Name	Type	Initial	Description
TrackNumber	INT		Number of the output; several position ranges per output are possible. [1..32]
FirstOnPosition	LREAL		Switch-on position of the output
LastOnPosition	LREAL		Switch-off position of the output
AxisDirection	INT		0: The output is switched in two directions 1: The output is only switched in positive direction -1: The output is only switched in positive direction
CamSwitchMode	INT		0: The tappets are calculated position-based 1: The tappets are calculated time-based, whereby only the value of FirstOnPosition will be used and the output stays TRUE for the given time (Duration).
Duration	TIME		Period of time for which the tappet output stays TRUE in case of CAMSwitchMode=1.

MC_TRACK_TR (STRUCT)

Name	Type	Initial	Description
OnCompensation	LREAL	0	A delay (value positive) or an early switch-on (value negative) can be set. The time is given in seconds.
OffCompensation	LREAL	0	A delay (value positive) or an early switch-on (value negative) can be set. The time is given in seconds.
Hysteresis	LREAL	0	Additionally a hysteresis can be set, which avoids a permanent switching of the output, which might occur e.g. if the servo-controller is exactly in switch-position and slightly swinging around that position due to the position control.


MC_TAPPETMODE (ENUM)

Name	Value	Description
tp_mode_auto	0	Auto mode
tp_mode_demandposition	1	Use set values
tp_mode_actualposition	2	Use actual values


NOTE

If following conditions are fulfilled, output might oscillate wrongly. Be sure to read below information and avoid that. By setting a certain time to OnCompensation, activated time of tappet output can be exactly 0, which is normally unnecessary usage. In that case, tappet output might oscillate. Be sure to set parameters so that tappet output is activated in a certain time.


7.4.4 MC_ReadActualTorque

Name	MC_ReadActualTorque		Type: FB
This FB returns the value of the actual torque.			
			
Name	Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	Enable	BOOL	TRUE: Enables the execution of the FB.
OUT	Valid	BOOL	TRUE: A valid output is available.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification
	Torque	LREAL	Value of current torque


7.4.5 MC_ReadActualVelocity

Name		MC_ReadActualVelocity		Type: FB
This FB returns the value of the actual velocity.				
				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Enable	BOOL	TRUE: Enables the execution of the FB.	
OUT	Valid	BOOL	TRUE: A valid output is available.	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	
	Velocity	LREAL	Value of current velocity	


7.4.6 MC_SetPosition

Name		MC_SetPosition		Type: FB
This FB shifts the coordinate system of an axis by manipulating both the set-point position as well as the actual position of an axis with the same value without any movement caused.				
				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Position	LREAL	Position unit [u]	
	Mode	BOOL	TRUE: Relative FALSE: Absolute	
OUT	Done	BOOL	TRUE: Position has been assigned to new value.	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

7.4.7 SMC_MoveContinuousAbsolute


Name		SMC_MoveContinuousAbsolute		Type: FB
This FB commands a controlled motion to a specified absolute position ending with the specified velocity.				
 <p>The diagram shows a rectangular function block titled "SMC_MoveContinuousAbsolute". On the left side, there are input lines with labels: Axis (type: AXIS_REF_SM3), Execute (type: BOOL), Position (type: LREAL), Velocity (type: LREAL), EndVelocity (type: LREAL), EndVelocityDirection (type: MC_Direction), Acceleration (type: LREAL), Deceleration (type: LREAL), Jerk (type: LREAL), and Direction (type: MC_Direction). On the right side, there are output lines with labels: InEndVelocity (type: BOOL), Busy (type: BOOL), CommandAborted (type: BOOL), Error (type: BOOL), and ErrorID (type: SMC_ERROR).</p>				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Position	LREAL	Target position [u] (positive or negative)	
	Velocity	LREAL	Maximum velocity [u/s] (positive)	
	EndVelocity	LREAL	End velocity [u/s] (positive)	
	EndVelocityDirection	MC_Direction	Determines direction of end velocity. Permissible values: current (2), positive (1), negative (-1), Not applicable: fastest (3), shortest (0) (Refer to section 7.9 Enumeration)	
	Acceleration	LREAL	Acceleration [u/s ²] (positive)	
	Deceleration	LREAL	Deceleration [u/s ²] (positive)	
	Jerk	LREAL	Jerk [u/s ³] (positive)	
	Direction	MC_Direction	Direction for linear/finite axes: positive (1), negative (-1) for rotary/modulo axes: fastest (3), current (2), positive (1), shortest (0), negative (-1) (Refer to section 7.9 Enumeration)	
OUT	InEndVelocity	BOOL	TRUE: Commanded position has been reached.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

7.4.8 MC_MoveContinuousRelative

Name		SMC_MoveContinuousRelative		Type: FB
This FB commands a controlled motion to a specified relative distance ending with the specified velocity.				
 <p>The diagram shows the SMC_MoveContinuousRelative function block with the following inputs and outputs:</p> <ul style="list-style-type: none"> Inputs: Axis (AXIS_REF_SM3), Execute (BOOL), Distance (LREAL), Velocity (LREAL), EndVelocity (LREAL), EndVelocityDirection (MC_Direction), Acceleration (LREAL), Deceleration (LREAL), Jerk (LREAL). Outputs: InEndVelocity (BOOL), Busy (BOOL), CommandAborted (BOOL), Error (BOOL), ErrorID (SMC_ERROR). 				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Distance	LREAL	Relative distance [u] (positive or negative)	
	Velocity	LREAL	Maximum velocity [u/s] (positive)	
	EndVelocity	LREAL	End velocity [u/s] (positive)	
	EndVelocityDirection	MC_Direction	Determines direction of end velocity. Permissible values: current (2), positive (1), negative (-1), Not applicable: fastest (3), shortest (0) (Refer to section 7.9 Enumeration)	
	Acceleration	LREAL	Acceleration [u/s ²] (positive)	
	Deceleration	LREAL	Deceleration [u/s ²] (positive)	
	Jerk	LREAL	Jerk [u/s ³] (positive)	
OUT	InEndVelocity	BOOL	TRUE: Commanded distance has been reached.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

7.5 PLCopen Part 3 for Single-Axis

7.5.1 MC_Jog


Name		MC_Jog		Type: FB
This FB commands a jogged movement to a specified axis as long as the input 'JogForward/Backward' is set.				
 <p>The diagram shows a rectangular function block labeled 'MC_Jog'. On the left side, there are seven input terminals: 'Axis' (type <i>AXIS_REF_SM3</i>), 'JogForward' (type <i>BOOL</i>), 'JogBackward' (type <i>BOOL</i>), 'Velocity' (type <i>LREAL</i>), 'Acceleration' (type <i>LREAL</i>), 'Deceleration' (type <i>LREAL</i>), and 'Jerk' (type <i>LREAL</i>). On the right side, there are four output terminals: 'Busy' (type <i>BOOL</i>), 'CommandAborted' (type <i>BOOL</i>), 'Error' (type <i>BOOL</i>), and 'ErrorId' (type <i>SMC_Error</i>).</p>				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	JogForward	BOOL	TRUE: Axis is moved with the specified dynamic values velocity, acceleration, deceleration and jerk in a positive direction. (No motion is executed if JogBackward is TRUE at the same time)	
	JogBackward	BOOL	TRUE: Axis is moved with the specified dynamic values velocity, acceleration, deceleration and jerk in a negative direction. (No motion is executed if JogForward is TRUE at the same time)	
	Velocity	LREAL	Maximum velocity [u/s] (positive)	
	Acceleration	LREAL	Acceleration [u/s ²] (positive)	
	Deceleration	LREAL	Deceleration [u/s ²] (positive)	
	Jerk	LREAL	Jerk [u/s ³] (positive)	
OUT	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

NOTE

When 'JogForward' input or 'JogBackward' input is reset (TRUE to FALSE), the specified axis is in deceleration. If the axis status changes to Errorstop while deceleration before stopping by an unexpected reason, for example limit switch detected, then 'Busy' output of MC_Jog is activated, and no command can be accepted. In this case, perform [Reset warm] or [Reset cold] to restart the PLC.

7.5.2 SMC_Inch


Name	SMC_Inch	Type: FB
This FB commands an inching movement to a specified axis as long as the moving distance is not reached and the input 'InchForward' or 'InchBackward' is set.		



Name	Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	InchForward	BOOL	TRUE: Axis is moved with the dynamic values velocity, acceleration, deceleration and jerk in a positive direction until distance has been travelled. If 'Inchforward' is set to FALSE and back to TRUE, a further motion is started. If 'Inchforward' is set to FALSE before distance has been travelled, the axis is immediately decelerated to the velocity value zero. 'Busy' is then set to FALSE. If 'InchBackward' and 'InchForward' are TRUE at the same time, then no motions are carried out.
	InchBackward	BOOL	TRUE: Axis is moved with the dynamic values velocity, acceleration, deceleration and jerk in a negative direction until distance has been travelled. If 'Inchforward' is set to FALSE and back to TRUE, a further motion is started. If 'Inchforward' is set to FALSE before distance has been travelled, the axis is immediately decelerated to the velocity value zero. 'Busy' is then set to FALSE. If 'InchBackward' and 'InchForward' are TRUE at the same time, then no motions are carried out.
	Distance	LREAL	Distance that is travelled [u] (positive)
	Velocity	LREAL	Maximum velocity [u/s] (positive)
	Acceleration	LREAL	Acceleration [u/s ²] (positive)
	Deceleration	LREAL	Deceleration [u/s ²] (positive)
	Jerk	LREAL	Jerk [u/s ³] (positive)
OUT	Busy	BOOL	TRUE: The FB is in operation.
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification

7.6 PLCopen for Multi-Axis

7.6.1 MC_CamIn

Name		MC_CamIn		Type: FB
This FB engages the CAM.				
 <p>The diagram shows the MC_CamIn function block with the following connections:</p> <ul style="list-style-type: none"> Inputs (left side): <ul style="list-style-type: none"> Master: <i>AXIS_REF_SM3</i> Slave: <i>AXIS_REF_SM3</i> Execute: <i>BOOL</i> MasterOffset: <i>LREAL</i> SlaveOffset: <i>LREAL</i> MasterScaling: <i>LREAL</i> SlaveScaling: <i>LREAL</i> StartMode: <i>MC_StartMode</i> CamTableID: <i>MC_CAM_ID</i> VelocityDiff: <i>LREAL</i> Acceleration: <i>LREAL</i> Deceleration: <i>LREAL</i> Jerk: <i>LREAL</i> TappetHysteresis: <i>LREAL</i> Outputs (right side): <ul style="list-style-type: none"> InSync: <i>BOOL</i> Busy: <i>BOOL</i> CommandAborted: <i>BOOL</i> Error: <i>BOOL</i> ErrorID: <i>SMC_ERROR</i> EndOfProfile: <i>BOOL</i> Tappets: <i>SMC_TappetData</i> 				
Name		Type	Description	
IN_OUT	Master	AXIS_REF_SM3	Reference to master axis	
	Slave	AXIS_REF_SM3	Reference to slave axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	MasterOffset	LREAL	Offset on master table	
	SlaveOffset	LREAL	Offset on slave table	
	MasterScaling	LREAL	Scaling factor for master profile	
	SlaveScaling	LREAL	Scaling factor for slave profile	
	StartMode	MC_StartMode	Start mode	
	CamTableID	MC_CAM_ID	Identification of the cam plate. The input is connected with the output of the instance of MC_CamTableSelect.	
	VelocityDiff	LREAL	Maximum velocity difference for 'ramp_in' mode. [u/s]	
	Acceleration	LREAL	Acceleration for 'ramp_in' mode. [u/s ²]	
	Deceleration	LREAL	Deceleration for 'ramp_in' mode. [u/s ²]	
	Jerk	LREAL	Jerk for 'ramp_in' mode. [u/s ³]	
	TappetHysteresis	LREAL	<p>Size of the hysteresis for tappets in [u]. A positive value means that the tappet cannot fire immediately after it has fired. The master position first needs to move away from the tappet by more than the value given for TappetHysteresis.</p> <p>For example, if the master is an encoder, the master position may oscillate by a few increments around the tappet position. Without a hysteresis, the tappet may fire all the time.</p>	
OUT	InSync	BOOL	TRUE: Cam has been engaged for the first time.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	
	EndOfProfile	BOOL	Pulsed output: Cyclic end of the cam profile	
	Tappets	SMC_TappetData	Tappets: Has to be evaluated by SMC_GetTappetValue FB.	

MC_STARTMODE (ENUM)

Name	Value	Description
absolute	0	Cam plate is positioned absolutely with respect to the current master and slave.
relative	1	Cam plate is positioned relative to the current master and slave.
ramp_in	2	With acceleration
ramp_in_pos	3	With acceleration in positive direction
ramp_in_neg	4	With acceleration in negative direction

SMC_TAPPETDATA (STRUCT)

Name	Type	Initial	Description
pTaps	ARRAY [0..2] OF POINTER TO SMC_CAMTappet		This is a STRUCT for interface between MC_CamIn output and SMC_GetTappetValue input.
dwCycleTime	DWORD		
byChannels	BYTE	3	
bRestart	BOOL		

SMC_CAMTAPPET (STRUCT)

Name	Type	Initial	Description
Ctt	SMC_CAMTAPPETTYPE (ENUM)		
Cta	SMC_CAMTAPPETACTION (ENUM)		
dwDelay	DWORD		In case of 'cta' =Tappetaction.tappetaction_time, this value determines the delay time [μ s]
dwDuration	DWORD		In case of 'cta' =Tappetaction.tappetaction_time, this value determines the time for which the tappet is switched to on. [μ s]
iGroupID	INT		Group or track ID of the tappet output that is switched.
x	LREAL		Master position where tappet is switched.
dwActive	DWORD	16#FFFFFFFF	Internal variable


SMC_CAMTAPPETTYPE (ENUM)

Name	Value	Description
TAPPET_pos	0	Tappet action active when the master passes its position in positive direction.
TAPPET_all	1	Tappet action active when the master passes its position in both directions.
TAPPET_neg	2	Tappet action active when the master passes its position in negative direction.


SMC_CAMTAPPETACTION (ENUM)

Name	Value	Description
TAPPETACTION_on	0	Switches on.
TAPPETACTION_off	1	Switches off
TAPPETACTION_inv	2	Inverts.
TAPPETACTION_time	3	Switches on after a delay for a certain time period.


7.6.2 MC_CamOut

Name		MC_CamOut		Type: FB
This FB disengages the slave axis from the master axis immediately.				
				
Name	Type	Description		
IN_OUT	Slave	AXIS_REF_SM3	Reference to the slave axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
OUT	Done	BOOL	TRUE: Cam has been disengaged.	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	


7.6.3 MC_CamTableSelect

Name		MC_CamTableSelect		Type: FB
This FB selects the CAM tables by setting the connections to the relevant tables.				
				
Name	Type	Description		
IN_OUT	Master	AXIS_REF_SM3	Reference to the master axis	
	Slave	AXIS_REF_SM3	Reference to the slave axis	
	CamTable	MC_CAM_REF	Reference to the cam description	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	Periodic	BOOL	TRUE: Periodic FALSE: Non periodic	
	MasterAbsolute	BOOL	TRUE: Absolute FALSE: Relative coordinates	
	SlaveAbsolute	BOOL	TRUE: Absolute FALSE: Relative coordinates	
OUT	Done	BOOL	TRUE: Preselection has been done.	
	Busy	BOOL	TRUE: The FB is in operation.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	
	CamTableID	MC_CAM_ID	Identifier of the cam table be used for the function block. (Connect to input of MC_CamIn)	

7.6.4 MC_GearIn

Name		MC_GearIn		Type: FB
This FB commands a ratio between the velocity of the slave and master axis.				
 <p>The diagram shows a central box labeled MC_GearIn. On the left side, there are seven input lines: Master (type <i>AXIS_REF_SM3</i>), Slave (type <i>AXIS_REF_SM3</i>), Execute (type <i>BOOL</i>), RatioNumerator (type <i>DINT</i>), RatioDenominator (type <i>UDINT</i>), Acceleration (type <i>LREAL</i>), and Deceleration (type <i>LREAL</i>). On the right side, there are five output lines: InGear (type <i>BOOL</i>), Busy (type <i>BOOL</i>), CommandAborted (type <i>BOOL</i>), Error (type <i>BOOL</i>), and ErrorID (type <i>SMC_ERROR</i>).</p>				
Name	Type	Description		
IN_OUT	Master	AXIS_REF_SM3	Reference to the master axis	
	Slave	AXIS_REF_SM3	Reference to the slave axis	
IN	Execute	BOOL	Starts the execution of the FB at rising edge.	
	RatioNumerator	DINT	Gear ratio Numerator	
	RatioDenominator	UDINT	Gear ratio Denominator	
	Acceleration	LREAL	Target acceleration when coupling[u/s ²]	
	Deceleration	LREAL	Target deceleration when coupling[u/s ²]	
	Jerk	LREAL	Jerk when coupling [u/s ³]	
OUT	InGear	BOOL	TRUE: Coupling has taken place.	
	Busy	BOOL	TRUE: The FB is in operation.	
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.	
	Error	BOOL	TRUE: Error has occurred within the FB.	
	ErrorID	SMC_ERROR	Error identification	

7.6.5 MC_GearInPos

Name	MC_GearInPos		Type: FB
This FB commands a gear ratio between the position of the slave and master from the synchronization point onwards.			
 <p>The diagram shows the MC_GearInPos function block with the following connections:</p> <ul style="list-style-type: none"> Master: AXIS_REF_SM3 Slave: AXIS_REF_SM3 Execute: BOOL RatioNumerator: DINT RatioDenominator: DINT MasterSyncPosition: LREAL SlaveSyncPosition: LREAL MasterStartDistance: LREAL AvoidReversal: BOOL StartSync: BOOL InSync: BOOL Busy: BOOL CommandAborted: BOOL Error: BOOL ErrorID: SMC_ERROR 			
Name	Type	Description	
IN_OUT	Master	AXIS_REF_SM3	Reference to the master axis
	Slave	AXIS_REF_SM3	Reference to the slave axis
IN	Execute	BOOL	Starts the execution of the FB at rising edge.
	RatioNumerator	DINT	Gear ratio Numerator
	RatioDenominator	DINT	Gear ratio Denominator
	MasterSyncPosition	LREAL	Master position where the axes run in sync.
	SlaveSyncPosition	LREAL	Slave position where the axes run in sync.
	MasterStartDistance	LREAL	Master distance for the gear in procedure (where the slave axis will be started for getting into synchronization). In other words, the slave is brought into sync with the master during this distance, i.e. from MasterSyncPosition - MasterStartDistance until MasterSyncPosition. If MasterStartDistance is 0 (or negative), then the slave movement is started immediately.
OUT	AvoidReversal	BOOL	TRUE: Signals that the reversal of the module slave is physically impossible or might lead to damage. FALSE: Signals that the reversal of the slave is physically possible and acceptable.
	StartSync	BOOL	TRUE: Commanded gearing has been started.
	InSync	BOOL	TRUE: Commanded gearing has been completed.
	Busy	BOOL	TRUE: The FB is in operation.
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification

7.6.6 MC_GearOut


Name		MC_GearOut	Type: FB
This FB disengages the slave axis from the master axis.			
Name		Type	Description
IN_OUT	Slave	AXIS_REF_SM3	Reference to the slave axis
IN	Execute	BOOL	Starts the execution of the FB at rising edge.
OUT	Done	BOOL	TRUE: Slave axis has been disengaged.
	Busy	BOOL	TRUE: The FB is in operation.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification

7.6.7 MC_Phasing


Name		MC_Phasing	Type: FB
<p>This Function Block creates a phase shift in the master position of a slave axis relative to the existing phase shift. The master position is shifted in relation to the real physical position.</p>			
<p>The diagram shows a central box labeled 'MC_Phasing'. On the left side, there are seven input lines: Master (type AXIS_REF_SM3), Slave (type AXIS_REF_SM3), Execute (type BOOL), PhaseShift (type LREAL), Velocity (type LREAL), Acceleration (type LREAL), Deceleration (type LREAL), and Jerk (type LREAL). On the right side, there are five output lines: Done (type BOOL), Busy (type BOOL), CommandAborted (type BOOL), Error (type BOOL), and ErrorID (type SMC_ERROR).</p>			
Name		Type	Description
IN_OUT	Master	AXIS_REF_SM3	Reference to the master axis
	Slave	AXIS_REF_SM3	Reference to the slave axis
IN	Execute	BOOL	Starts the execution of the FB at rising edge.
	PhaseShift	LREAL	Phase difference between master and slave [u]
	Velocity	LREAL	Maximum velocity for reaching phase difference [u/s]
	Acceleration	LREAL	Maximum acceleration for reaching phase difference [u/s ²]
	Deceleration	LREAL	Maximum deceleration for reaching phase difference [u/s ²]
	Jerk	LREAL	Maximum jerk for reaching phase difference [u/s ³]
OUT	Done	BOOL	TRUE: Commanded phasing has been reached.
	Busy	BOOL	TRUE: The FB is in operation.
	CommandAborted	BOOL	TRUE: Command has been aborted by another command.
	Error	BOOL	TRUE: Error has occurred within the FB.
	ErrorID	SMC_ERROR	Error identification

7.7 Utility Function Blocks

7.7.1 SMC3_ReinitDrive


Name		SMC3_ReinitDrive	Type: FB
This FB reinitiates a drive/axis. That means that the start-up phase is run through again and the application cannot control the drive until the function block set bDone = TRUE.			
 <p>The diagram shows the SMC3_ReinitDrive function block with the following connections:</p> <ul style="list-style-type: none"> Input: Axis (type: AXIS_REF_SM3) Input: bExecute (type: BOOL) Input: bVirtual (type: BOOL) Output: bDone (type: BOOL) Output: bBusy (type: BOOL) Output: bError (type: BOOL) Output: nErrorID (type: SMC_ERROR) 			
Name	Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis
IN	bExecute	BOOL	Starts the execution of the FB at rising edge.
	bVirtual	BOOL	TRUE: Virtual mode
OUT	bDone	BOOL	TRUE: Reinitialization has been completed.
	bBusy	BOOL	TRUE: The FB is in operation.
	bError	BOOL	TRUE: Error has occurred within the FB.
	nErrorID	SMC_ERROR	Error identification

7.7.2 SMC_GetTappetValue

Name		SMC_GetTappetValue	Type: FB
This FB evaluates the output Tappets of function block MC_CamIn and contains the current tappet status.			
 <p>The diagram shows the SMC_GetTappetValue function block with the following connections:</p> <ul style="list-style-type: none"> Input: Tappets (type: SMC_TappetData) Input: iID (type: INT) Input: bInitValue (type: BOOL) Input: bSetInitValueAtReset (type: BOOL) Output: bTappet (type: BOOL) 			
Name	Type	Description	
IN_OUT	Tappets	SMC_TappetData	Tappet signals to be evaluated by MC_GetTappetValue
IN	iID	INT	Group ID of the tappet to be evaluated
	bInitValue	BOOL	Initial value of the tappet to be assigned at first call
	bSetInitValueAtReset	BOOL	TRUE: Sets the value of the tappet to bInitValue at a restart of the MC_CamIn FB. FALSE: Retains the tappet value at a restart of the MC_CamIn FB.
OUT	bTappet	BOOL	Tappet value


7.7.3 SMC_Homing

Name	SMC_Homing	Type: FB
<p>This FB causes the execution of a homing drive of the axis. If SMC_Homing is executed, the axis is moved at fVelocityFast in the direction specified by nDirection as long as bEndSwitch = FALSE. The reference switch is then closed. The axis is decelerated and driven at fVelocitySlow in the opposite direction. At the point at which the reference switch opens with bEndSwitch = TRUE, the reference position fHomePosition is set and the drive is stopped.</p>		




Name	Type	Description
IN_OUT	Axis	AXIS_REF_SM3 Reference to the axis
IN	bExecute	BOOL Starts the execution of the FB at rising edge.
	fHomePosition	LREAL Home position taken after homing completed [u].
	fVelocitySlow	LREAL Low velocity; used to drive out of the reference switch [u/s]
	fVelocityFast	LREAL High velocity; used until reference switch is found [u/s]
	fAcceleration	LREAL Acceleration [u/s ²] (positive)
	fDeceleration	LREAL Deceleration [u/s ²] (positive)
	fJerk	LREAL Jerk [u/s ³] (positive)
	nDirection	MC_Direction Direction positive (1), negative (-1) (Refer to 7.9)
	bReferenceSwitch	BOOL TRUE: Switches the reference.
	fSignalDelay	LREAL Time [s] for bReferenceSwitch to be transmitted. (The result of (fVelocitySlow * fSignalDelay) will be added to home position as a offset after homing done.)
	nHomingMode	SMC_HOMING_MODE Homing mode (Refer to 7.9 Enumeration)
	bReturnToZero	BOOL TRUE: Moves to position zero after homing.
	bIndexOccured	BOOL Index pulse
fIndexPosition	LREAL Position where index occurred	
bIgnoreHWLimit	BOOL TRUE: Sets bHWLimitEnable (parameter in AXIS_REF_SM3) = FALSE during homing.	
OUT	bDone	BOOL TRUE: Homing has been done.
	bBusy	BOOL TRUE: The FB is in operation.
	bCommandAborted	BOOL TRUE: Command has been aborted by another command.
	bError	BOOL TRUE: Command has been aborted by another command.
	nErrorID	SMC_ERROR TRUE: Error has occurred within the FB.
	bStartLatchingIndex	BOOL For some homing modes, the index pulse is evaluated. TRUE: Storing of the index pulse has been started and must be done by the application. The result is expected in the inputs bIndexOccured and fIndexPosition.


7.7.4 SMC_SetTorque

Name		SMC_SetTorque		Type: FB
This FB can be used to create a torque if the drive is in controller mode "torque".				
				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	bEnable	BOOL	TRUE: Enables the execution of the FB.	
	fTorque	LREAL	Torque [Nm]	
OUT	bBusy	BOOL	TRUE: The FB is in operation.	
	bError	BOOL	TRUE: Error has occurred within the FB.	
	nErrorID	SMC_ERROR	Error identification	


7.7.5 SMC_SetControllerMode

Name		SMC_SetControllerMode		Type: FB
This FB sets the byControllerMode (command value of operation mode) parameter of the axis and waits until the parameter byRealControllerMode (actual value of operation mode) reflects this value.				
				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	bExecute	BOOL	Starts the execution of the FB at rising edge.	
	nControllerMode	SMC_CONTROLLER_MODE	Controller mode (ENUM)	
OUT	bDone	BOOL	TRUE: Mode switching has been done.	
	bBusy	BOOL	TRUE: The FB is in operation.	
	bError	BOOL	TRUE: Error has occurred within the FB.	
	nErrorID	SMC_ERROR	Error identification	


7.7.6 SMC_SetMovementType

Name		SMC_SetMovementType		Type: FB
This FB sets the movement type of a virtual axis to linear or modulo.				
 <p>The diagram shows a rectangular function block labeled SMC_SetMovementType. On the left side, there are four input lines: <i>Axis</i> (type <i>AXIS_REF_SM3</i>), <i>bExecute</i> (type <i>BOOL</i>), <i>iMovementType</i> (type <i>INT</i>), and <i>fPositionPeriod</i> (type <i>LREAL</i>). On the right side, there are three output lines: <i>bDone</i> (type <i>BOOL</i>), <i>bError</i> (type <i>BOOL</i>), and <i>eErrorID</i> (type <i>SMC_ERROR</i>).</p>				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	bExecute	BOOL	Starts the execution of the FB at rising edge.	
	iMovementType	INT	0: modulo 1: linear	
	fPositionPeriod	LREAL	The new position period for modulo movement, must be positive	
OUT	bDone	BOOL	TRUE: Movement setting has been done.	
	bError	BOOL	TRUE: Error has occurred within the FB.	
	eErrorID	SMC_ERROR	Error identification	

7.7.7 SMC_SetRampType

Name		SMC_SetRampType		Type: FB
This FB sets the ramp type of an axis to a new value. Can only be used when the axis is in state standstill or power_off.				
 <p>The diagram shows a rectangular function block labeled SMC_SetRampType. On the left side, there are three input lines: <i>Axis</i> (type <i>AXIS_REF_SM3</i>), <i>bExecute</i> (type <i>BOOL</i>), and <i>eRampType</i> (type <i>SMC_RAMPTYPE</i>). On the right side, there are three output lines: <i>bDone</i> (type <i>BOOL</i>), <i>bError</i> (type <i>BOOL</i>), and <i>eErrorID</i> (type <i>SMC_ERROR</i>).</p>				
Name	Type	Description		
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	bExecute	BOOL	Starts the execution of the FB at rising edge.	
	eRampType	SMC_RAMPTYPE (ENUM)	Defines the new ramp type	
OUT	bDone	BOOL	TRUE: Ramp type has been set.	
	bError	BOOL	TRUE: Error has occurred within the FB.	
	eErrorID	SMC_ERROR (ENUM)	Error identification	

7.7.8 SMC_InPosition

Name		SMC_InPosition		Type: FB
This FB monitors the offset between the nominal and actual positions of an axis (drag error). This tests whether the drag error lies within a specified value range for over a defined period of time (position window).				
 <p style="text-align: center;">SMC_InPosition</p> <p> <input type="checkbox"/> Axis <i>AXIS_REF_SM3</i> <i>BOOL</i> bInPosition <input type="checkbox"/> bEnable <i>BOOL</i> <i>BOOL</i> bBusy <input type="checkbox"/> fPosWindow <i>LREAL</i> <i>BOOL</i> bTimeOut <input type="checkbox"/> fPosTime <i>LREAL</i> <input type="checkbox"/> fTimeOut <i>LREAL</i> </p>				
Name		Type	Description	
IN_OUT	Axis	AXIS_REF_SM3	Reference to the axis	
IN	bEnable	BOOL	TRUE: Enables the execution of the FB.	
	fPosWindow	LREAL	The drive is inside the position window, if fPosWindow >= Distance (actual position, set position) [u].	
	fPosTime	LREAL	Time that the FB has to stay inside the position window before bInPosition is set [s].	
	fTimeOut	LREAL	If the time since enabling the FB is larger than this value and bInPosition is not set, bTimeOut is set; this mechanism is deactivated, if fTimeOut = 0.	
OUT	bInPosition	BOOL	TRUE: Parameter is available	
	bBusy	BOOL	TRUE: The FB is in operation.	
	bTimeout	BOOL	TRUE: Error has occurred within the FB.	

7.8 STRUCT

7.8.1 MC_TP_REF

Name	Type	Initial	Description
Number_of_pairs	INT	0	This variable is not used.
IsAbsolute	BOOL	TRUE	TRUE: Absolute FALSE: Relative
MC_TP_Array	ARRAY [1..100] OF SMC_TP		Time/Positions

7.8.2 MC_TV_REF

Name	Type	Initial	Description
Number_of_pairs	INT	0	This variable is not used.
IsAbsolute	BOOL	TRUE	TRUE: Absolute FALSE: Relative
MC_TV_Array	ARRAY [1..100] OF SMC_TV		Time/Velocity

7.8.3 MC_TA_REF

Name	Type	Initial	Description
Number_of_pairs	INT	0	This variable is not used.
IsAbsolute	BOOL	TRUE	TRUE: Absolute FALSE: Relative
MC_TA_Array	ARRAY [1..100] OF SMC_TA		Time/Acceleration

7.8.4 SMC_TP

Name	Type	Initial	Description
delta_time	TIME	0	Period of time between reaching the last and the current point
position	LREAL	0	Position

7.8.5 SMC_TV

Name	Type	Initial	Description
delta_time	TIME	0	Period of time between reaching the last and the current point
Velocity	LREAL	0	Velocity

7.8.6 SMC_TA

Name	Type	Initial	Description
delta_time	TIME	0	Period of time between reaching the last and the current point
Acceleration	LREAL	0	Acceleration

7.8.7 TRIGGER_REF

Name	Type	Initial	Description
iTriggerNumber	INT	-1	Trigger channel; defined by driver (only used when bFastLatching=TRUE)
bFastLatching	BOOL	TRUE	TRUE: Latching is done in drive (precise) FALSE: Latching is done with bInput in the cycle of the motion task (unprecise).
bInput	BOOL		Trigger signal when bFastLatching=FALSE.
bActive	BOOL	FALSE	Internal variable

7.8.8 MC_CAMSWITCH_REF

Name	Type	Initial	Description
NoOfSwitches	BYTE	0	Number of switch positions
CamSwitchPtr	POINTER TO MC_CAMSWITCH_TR	0	Address of MC_CAMSWITCH_TR

7.8.9 MC_CAMSWITCH_TR

Name	Type	Initial	Description
TrackNumber	INT		Number of the output; several position ranges per output are possible. [1..32]
FirstOnPosition	LREAL		Switch-on position of the output
LastOnPosition	LREAL		Switch-off position of the output
AxisDirection	INT		0: The output is switched in two directions 1: The output is only switched in positive direction 2: The output is only switched in negative direction
CamSwitchMode	INT		0: The tappets are calculated position-based 1: The tappets are calculated time-based, whereby only the value of FirstOnPosition will be used and the output stays TRUE for the given time 'Duration'.
Duration	TIME		Period of time for which the tappet output stays TRUE in case of CamSwitchMode=1.

7.8.10 MC_CAM_ID

Name	Type	Initial	Description
pCT	POINTER TO BYTE		This STRUCT is an interface between output of MC_CamTableSelect and input of MC_CamIn.
Periodic	BOOL	FALSE	
MasterAbsolute	BOOL	FALSE	
SlaveAbsolute	BOOL	FALSE	
StartMaster	LREAL	0	
EndMaster	LREAL	0	
StartSlave	LREAL	0	
EndSlave	LREAL	0	
byCompatibilityMode	BYTE		

7.8.11 SMC_TAPPETDATA

Name	Type	Initial	Description
pTaps	ARRAY [0..2] OF POINTER TO SMC_CAMTappet		This STRUCT is an interface between output of MC_CamIn and input of SMC_GetTappetValue.
dwCycleTime	DWORD		
byChannels	BYTE	3	
bRestart	BOOL		

7.8.12 SMC_CAMTAPPET

Name	Type	Initial	Description
ctt	SMC_CAMTAPPETTYPE (ENUM)		
cta	SMC_CAMTAPPETACTION (ENUM)		
dwDelay	DWORD		In case of cta = TAPPETACTION.TAPPETACTION_time, this value determines the delay time in μ s.
dwDuration	DWORD		In case of cta = TAPPETACTION.TAPPETACTION_time, this value determines the time in μ s, for which the tappet is switched to on.
iGroupID	INT		Group or track ID of the tappet output that is switched.
x	LREAL		Master position where tappet is switched.
dwActive	DWORD	16#FFFFFFFF	Internal variable

7.8.13 MC_TRACK_TR

Name	Type	Initial	Description
OnCompensation	LREAL		ON delay time [s]
OffCompensation	LREAL		OFF delay time [s]
Hysteresis	LREAL		Hysteresis

7.9 Enumeration (ENUM)

7.9.1 MC_DIRECTION

Name	Value	Description
fastest	3	Selects the direction automatically in order to reach the target position as fast as possible (only modulo axes).
current	2	Keeps the current direction to reach the target (only modulo axes).
positive	1	Moves in positive direction.
shortest	0	Selects the direction according to the shortest distance (only modulo axes).
negative	-1	Moves in negative direction.

7.9.2 MC_TAPPETMODE

Name	Value	Description
tp_mode_auto	0	Auto mode
tp_mode_demandposition	1	Use set values
tp_mode_actualposition	2	Use actual values

7.9.3 MC_STARTMODE

Name	Value	Description
absolute	0	Absolute position
relative	1	Relative position
ramp_in	2	With acceleration
ramp_in_pos	3	With acceleration (positive)
ramp_in_neg	4	With acceleration (negative)

7.9.4 SMC_CAMTAPPETTYPE

Name	Value	Description
TAPPET_pos	0	Tappet action active when the master passes its position in positive direction.
TAPPET_all	1	Tappet action active when the master passes its position in both directions.
TAPPET_neg	2	Tappet action active when the master passes its position in negative direction.

7.9.5 SMC_CAMTAPPETACTION

Name	Value	Description
TAPPETACTION_on	0	Switches on.
TAPPETACTION_off	1	Switches off.
TAPPETACTION_inv	2	Inverts.
TAPPETACTION_time	3	Switches on after a delay for a certain time period.

7.9.6 SMC_RAMPTYPE

Name	Value	Description
trapez	0	Trapezoid
sinsquare	1	Sin^2
quadratic_ramp	2	Quadratic ramp
quadratic_smooth_ramp	3	Quadratic ramp (smooth)

7.9.7 SMC_CONTROLLER_MODE

Name	Value	Description
SMC_nocontrol	0	—
SMC_torque	1	Torque
SMC_velocity	2	Velocity
SMC_position	3	Position
SMC_current	4	Current

7.9.8 SMC_HOMING_MODE

Name	Value	Description
FAST_BSLow_S_STOP	0	Move with fast velocity onto the reference switch; invert and move with slow velocity out of the reference switch; execute “Set position”; stop
FAST_BSLow_STOP_S	1	Move with fast velocity onto the reference switch; invert and move with slow velocity out of the reference switch; stop; execute “Set position”
FAST_BSLow_I_S_STOP	2	Move with fast velocity onto the reference switch; invert and move with slow velocity out of the reference switch; wait for the index pulse; execute “Set position”; stop
FAST_SLOW_S_STOP	4	Move with fast velocity onto the reference switch; move with slow velocity out of the reference switch; execute “Set position”; stop
FAST_SLOW_STOP_S	5	Move with fast velocity onto the reference switch; move with slow velocity out of the reference switch; stop; execute “Set position”
FAST_SLOW_I_S_STOP	6	Move with fast velocity onto the reference switch; move with slow velocity out of the reference switch; wait for the index pulse; execute “Set position”; stop

7.9.9 SMC_ERROR

Name	Value	Description
SMC_NO_ERROR	0	No error
SMC_DI_GENERAL_COMMUNICATION_ERROR	1	Communication error. For example, Sercos ring has broken.
SMC_DI_AXIS_ERROR	2	Axis error
SMC_DI_FIELDBUS_LOST_SYNCRONICITY	3	Fieldbus has lost synchronism
SMC_DI_SWLIMITS_EXCEEDED	10	Position outside of permissible range of SWLimit
SMC_DI_HWLIMITS_EXCEEDED	11	Hardware end switch is active
SMC_DI_LINEAR_AXIS_OUTOFRANGE	12	This error occurs if a linear axis has more than 2^{15} 32-bit overflows of the position in increments
SMC_DI_HALT_OR_QUICKSTOP_NOT_SUPPORTED	13	Drive status Halt or Quickstop is not supported
SMC_DI_VOLTAGE_DISABLED	14	Drive has no power
SMC_DI_IRREGULAR_ACTPOSITION	15	This error is no longer used
SMC_DI_POSITIONLAGERROR	16	Position lag error. Difference between set and current position exceeds the given limit
SMC_DI_HOMING_ERROR	17	Homing error reported by axis
SMC_REGULATOR_OR_START_NOT_SET	20	A problem with the license occurred
SMC_WRONG_CONTROLLER_MODE	21	Controller enable not done or brake applied
SMC_INVALID_ACTION_FOR_LOGICAL	25	Axis in wrong controller mode
SMC_FB_WASNT_CALLED_DURING_MOTION	30	Motion creating module has not been called again before end of the motion
SMC_AXIS_IS_NO_AXIS_REF	31	Type of given AXIS_REF variable is not AXIS_REF
SMC_AXIS_REF_CHANGED_DURING_OPERATION	32	AXIS_REF variable has been exchanged while the module was active.
SMC_FB_ACTIVE_AXIS_DISABLED	33	Axis disabled while being moved. MC_Power.bRegulatorOn
SMC_AXIS_NOT_READY_FOR_MOTION	34	Axis in its current state cannot execute a motion command, because the axis doesn't signal currently that it follows the target values.
SMC_AXIS_ERROR_DURING_MOTION	35	The drive reported an error during an ongoing movement.
SMC_VD_MAX_VELOCITY_EXCEEDED	40	Maximum velocity fMaxVelocity exceeded
SMC_VD_MAX_ACCELERATION_EXCEEDED	41	Maximum acceleration fMaxAcceleration exceeded
SMC_VD_MAX_DECELERATION_EXCEEDED	42	Maximum deceleration fMaxDeceleration exceeded
SMC_3SH_INVALID_VELACC_VALUES	50	Invalid velocity or acceleration values (SMC_Homing)
SMC_3SH_MODE_NEEDS_HWLIMIT	51	Mode requests for safety reasons use of end switches. (SMC_Homing)
SMC_FRC_NO_FREE_HANDLE	60	No free handle has been sent to open file.
SMC_SCM_NOT_SUPPORTED	70	Mode not supported (SMC_SetControllerMode)
SMC_SCM_AXIS_IN_WRONG_STATE	71	In current mode, controller mode cannot be changed. (SMC_SetControllerMode)
SMC_SCM_INTERRUPTED	72	SMC_SetControllerMode has been interrupted by MC_Stop or errorstop.
SMC_ST_WRONG_CONTROLLER_MODE	75	Axis not in correct controller mode. Deprecated, no longer returned by SMC_SetTorque.
SMC_RAG_ERROR_DURING_STARTUP	80	Error at startup of the axis group (SMC_ResetAxisGroup)
SMC_RAG_ERROR_AXIS_NOT_INITIALIZED	81	The axis is not yet in the required state.

Name	Value	Description
SMC_PP_WRONG_AXIS_TYPE	85	The function block does not support virtual or logical axes.
SMC_PP_NUMBER_OF_ABSOLUTE_BITS_INVALID	86	The number of absolute bits is invalid, must be in the range 8 .. 32.
SMC_CGR_ZERO_VALUES	90	Invalid values (SMC_ChangeGearingRatio)
SMC_CGR_DRIVE_POWERED	91	Gearing parameters must not be changed as long as the drive is under control. (SMC_ChangeGearingRatio)
SMC_CGR_INVALID_POSPERIOD	92	Invalid modulo period (≤ 0 or greater than half the bus bandwidth) (SMC_ChangeGearingRatio)
SMC_CGR_POSPERIOD_NOT_INTEGRAL	93	The modulo period in increments is not an integer, but the modulo-handling is done by the drive. (SMC_ChangeGearingRatio)
SMC_P_FTASKCYCLE_EMPTY	110	Axis contain no information on cycle time (fTaskCycle = 0). (MC_Reset)
SMC_R_NO_ERROR_TO_RESET	120	Axis without error (MC_Reset)
SMC_R_DRIVE_DOESNT_ANSWER	121	Axis does not perform error-reset. (MC_Reset)
SMC_R_ERROR_NOT_RESETTABLE	122	Error could not be reset. (MC_Reset)
SMC_R_DRIVE_DOESNT_ANSWER_IN_TIME	123	Communication with the axis did not work. (MC_Reset)
SMC_RP_PARAM_UNKNOWN	130	Parameter number unknown (MC_ReadParameter)
SMC_RP_REQUESTING_ERROR	131	Error during transmission to the drives. See error number in function block instance ReadDriveParameter. (MC_ReadParameter)
SMC_RP_DRIVE_PARAMETER_NOT_MAPPED	132	No assignment for drive parameters available (MC_ReadParameter)
SMC_RP_PARAM_CONVERSION_ERROR	133	Conversion of the value to / from the drive parameters failed. Unknown SoftMotion parameters (MC_ReadParameter)
SMC_WP_PARAM_INVALID	140	Parameter number unknown or writing not allowed (MC_WriteParameter)
SMC_WP_SENDING_ERROR	141	See error number in function block instance WriteDriveParameter (MC_WriteParameter)
SMC_WP_DRIVE_PARAMETER_NOT_MAPPED	142	No assignment for drive parameters available (MC_WriteParameter)
SMC_WP_PARAM_CONVERSION_ERROR	143	Conversion of the value to / from the drive parameters failed. Unknown SoftMotion parameters (MC_WriteParameter)
SMC_H_AXIS_WASNT_STANDSTILL	170	Axis has not been in standstill state. (MC_Home)
SMC_H_AXIS_DIDNT_START_HOMING	171	Error at start of homing action. (MC_Home)
SMC_H_AXIS_DIDNT_ANSWER	172	Error at start of homing action. (MC_Home)
SMC_H_ERROR_WHEN_STOPPING	173	Error at stop after homing. Deceleration may not be set. (MC_Home)
SMC_H_AXIS_IN_ERRORSTOP	174	Drive is in errorstop status. Homing cannot be executed. (MC_Home)
SMC_MS_UNKNOWN_STOPPING_ERROR	180	Unknown error at stop (MC_Stop)
SMC_MS_INVALID_ACCDEC_VALUES	181	Invalid velocity or acceleration values (MC_Stop)
SMC_MS_DIRECTION_NOT_APPLICABLE	182	Direction = shortest not applicable (MC_Stop)

Name	Value	Description
SMC_MS_AXIS_IN_ERRORSTOP	183	Drive is in errorstop status. Stop cannot be executed (MC_Stop)
SMC_BLOCKING_MC_STOP_WASNT_CALLED	184	Instance of MC_Stop blocking the axis by Execute = TRUE has not been called yet. MC_Stop (Execute = FALSE) has to be called.
SMC_UNKNOWN_TASK_INTERVAL	200	The task interval of the bus task could not be determined.
SMC_MA_INVALID_VELACC_VALUES	201	Invalid velocity or acceleration values (MC_MoveAbsolute)
SMC_MA_INVALID_DIRECTION	202	Direction error (MC_MoveAbsolute)
SMC_MR_INVALID_VELACC_VALUES	226	Invalid velocity or acceleration values (MC_MoveRelative)
SMC_MR_INVALID_DIRECTION	227	Direction error (MC_MoveRelative)
SMC_MAD_INVALID_VELACC_VALUES	251	Invalid velocity or acceleration values (MC_MoveAdditive)
SMC_MAD_INVALID_DIRECTION	252	Direction error (MC_MoveAdditive)
SMC_MSI_INVALID_VELACC_VALUES	276	Invalid velocity or acceleration values (MC_MoveSuperImposed)
SMC_MSI_INVALID_DIRECTION	277	Direction error (MC_MoveSuperImposed)
SMC_LOGICAL_NO_REAL_AXIS	300	No longer used; only for compatibility
SMC_MV_INVALID_ACCDEC_VALUES	301	Invalid velocity or acceleration values (MC_MoveVelocity)
SMC_MV_DIRECTION_NOT_APPLICABLE	302	Direction = shortest/fastest not applicable (MC_MoveVelocity)
SMC_PP_ARRAYSIZE	325	Erroneous array size (MC_PositionProfile)
SMC_PP_STEP0MS	326	Step time = t#0s (MC_PositionProfile)
SMC_VP_ARRAYSIZE	350	Erroneous array size (MC_VelocityProfile)
SMC_VP_STEP0MS	351	Step time = t#0s (MC_VelocityProfile)
SMC_AP_ARRAYSIZE	375	Erroneous array size (MC_AccelerationProfile)
SMC_AP_STEP0MS	376	Step time = t#0s (MC_AccelerationProfile)
SMC_TP_TRIGGEROCCUPIED	400	Trigger already active (MC_TouchProbe)
SMC_TP_COULDNT_SET_WINDOW	401	DriveInterface does not support the window function. (MC_TouchProbe)
SMC_TP_COMM_ERROR	402	Communication error (MC_TouchProbe)
SMC_AT_TRIGGERNOTOCCUPIED	410	Trigger already de-allocated (MC_AbortTrigger)
SMC_MCR_INVALID_VELACC_VALUES	426	Invalid velocity or acceleration values (MC_MoveContinuousRelative)
SMC_MCR_INVALID_DIRECTION	427	Invalid direction (MC_MoveContinuousRelative)
SMC_MCA_INVALID_VELACC_VALUES	451	Invalid velocity or acceleration values (MC_MoveContinuousAbsolute)
SMC_MCA_INVALID_DIRECTION	452	Invalid direction (MC_MoveContinuousAbsolute)
SMC_MCA_DIRECTION_NOT_APPLICABLE	453	Direction = fastest not applicable (MC_MoveContinuousAbsolute)
SMC_SDL_INVALID_AXIS_STATE	475	SMC_ChangeDynamicLimits may only be called in state standstill or power_off. (SMC_changeDynamicLimits)
SMC_SDL_INVALID_VELACC_VALUES	476	Invalid velocity, acceleration, deceleration or jerk values (SMC_changeDynamicLimits)

Name	Value	Description
SMC_CR_NO_TAPPETS_IN_CAM	600	Cam does not contain any tappets. (SMC_CamRegister)
SMC_CR_TOO_MANY_TAPPETS	601	Tappet group ID exceeds MAX_NUM_TAPPETS (SMC_CamRegister)
SMC_CR_MORE_THAN_32_ACCESSES	602	More than 32 accesses on one CAM_REF (SMC_CamRegister)
SMC_CI_NO_CAM_SELECTED	625	No cam selected (MC_CamIn)
SMC_CI_MASTER_OUT_OF_SCALE	626	Master axis out of valid range (MC_CamIn)
SMC_CI_RAMPIN_NEEDS_VELACC_VALUES	627	Velocity and acceleration values must be specified for ramp_in function (MC_CamIn)
SMC_CI_SCALING_INCORRECT	628	Scaling variables fEditor/TableMasterMin/Max are not correct (MC_CamIn)
SMC_CI_TOO_MANY_TAPPETS_PER_CYCLE	629	Too many tappets became active during one cycle (MC_CamIn)
SMC_CB_NOT_IMPLEMENTED	640	Function block for the given cam format is not implemented (SMC_CAMBounds, SMC_CAMBounds_Pos)
SMC_GI_RATIO_DENOM	675	RatioDenominator = 0 (MC_GearIn)
SMC_GI_INVALID_ACC	676	Acceleration invalid (MC_GearIn)
SMC_GI_INVALID_DEC	677	Deceleration invalid (MC_GearIn)
SMC_GI_MASTER_REGULATOR_CHANGED	678	Status Enable/Disable of the master has changed without permission (MC_GearIn)
SMC_GI_INVALID_JERK	679	Jerk invalid (MC_GearIn)
SMC_PH_INVALID_VELACCDEC	725	Velocity and acceleration/deceleration values invalid (MC_Phase)
SMC_PH_ROTARYAXIS_PERIOD0	726	Rotation axis with fPositionPeriod = 0 (MC_Phase)
SMC_NO_CAM_REF_TYPE	750	Type of given cam is not MC_CAM_REF.
SMC_CAM_TABLE_DOES_NOT_COVER_MASTER_SCALE	751	Master area, xStart and xEnd, from CamTable is not covered by curve data. (MC_CamTableSelect)
SMC_CAM_TABLE_EMPTY_MASTER_RANGE	752	Cam data table has empty master range. (MC_CamTableSelect)
SMC_CAM_TABLE_INVALID_MASTER_MINMAX	753	Cam data master has invalid max-, min-values. (MC_CamTableSelect)
SMC_CAM_TABLE_INVALID_SLAVE_MINMAX	754	Cam data slave has invalid max-, min-values. (MC_CamTableSelect)
SMC_GIP_MASTER_DIRECTION_CHANGE	775	During coupling of slave axis, master axis has changed direction of rotation. (MC_GearInPos)
SMC_GIP_SLAVE_REVERSAL_CANNOT_BE_AVOIDED	776	Input AvoidReversal is set, but slave reversal cannot be avoided. (MC_GearInPos)
SMC_GIP_AVOID_REVERSAL_FOR_FINITE_AXIS	777	Input AvoidReversal must not be set for finite slave axes. (MC_GearInPos)
SMC_BC_BL_TOO_BIG	800	Gear backlash fBacklash too large (> position period/2) (SMC_BacklashCompensation)
SMC_QPROF_DIVERGES	825	Internal error: computation of quadratic trajectory failed
SMC_QPROF_INVALID_PARAMETER	826	Internal error: computation of quadratic trajectory failed
SMC_QPROF_NO_RESULT	827	Internal error: computation of quadratic trajectory failed
SMC_QPROF_INVALID_NEW_LBD	828	Internal error: computation of quadratic trajectory failed

Name	Value	Description
SMC_QPROF_BAD_NEGOTIATION	829	Internal error: computation of quadratic trajectory failed
SMC_QPROF_INVALID_INTERVAL	830	Internal error: computation of quadratic trajectory failed
SMC_QPROF_NOT_ENOUGH_PHASES	831	Internal error: computation of quadratic trajectory failed
SMC_SRT_NOT_STANDSTILL_OR_POWEROFF	850	Action only permitted in standstill or power_off. (SMC_SetRampType)
SMC_SRT_INVALID_RAMPTYPE	851	Invalid ramp type (SMC_SetRampType)
SMC_SMT_NOT_STANDSTILL_OR_POWEROFF	852	Action only permitted in standstill or power_off. (SMC_SetMovementType)
SMC_SMT_INVALID_MOVEMENTTYPE_OR_POSITIONPERIOD	853	Invalid motion type or position period (SMC_SetMovementType)
SMC_SMT_AXIS_NOT_VIRTUAL	854	Function block only applicable to virtual axis. (SMC_SetMovementType)

Chapter 8 Visualization Template

8.1 Overview

Visualization templates enable efficient debugging without inputs and outputs for function blocks in POU.

MC_Power
Instance: POU.MC_Power_0


Enable	<input type="radio"/>	Status	<input checked="" type="radio"/>
bRegulatorOn	<input type="radio"/>	bRegulatorRealState	<input checked="" type="radio"/>
bDriveStart	<input type="radio"/>	bDriveStartRealState	<input checked="" type="radio"/>
		Busy	<input type="radio"/>
		Error	<input type="radio"/>
		ErrorID	<input type="text" value="0"/>

MC_MoveRelative
Instance: POU.MC_MoveRelative_0

Execute	<input type="radio"/>	Done	<input checked="" type="radio"/>
Distance	<input type="text" value="360.000000"/>	Busy	<input type="radio"/>
Velocity	<input type="text" value="360.000000"/>	CommandAborted	<input type="radio"/>
Acceleration	<input type="text" value="360.000000"/>	Error	<input type="radio"/>
Deceleration	<input type="text" value="360.000000"/>	ErrorID	<input type="text" value="0"/>
Jerk	<input type="text" value="0.000000"/>		

8.2 Programming and Operation

This is a simple program including MC_Power and MC_MoveRelative only. As shown below, all the inputs and outputs other than Axis input can be opened.





Right click on [Application] and choose [Add Object]-[Visualization...].




NOTE

When [Visualization] is added, also [WebVisualization] is added together automatically. However, the motion type CPU (HX-CP1S08M) does not support WebVisualization. It works only 30 minutes as a demo mode.


If you click [SM3_Basic] in the Visualization page, the templates for all FBs in SM3_Basic library appear. Drag VISU_MC_Power or VISU_NEW_MC_Power to the Visualization page.





Then [Assign parameters] dialog appears. Click [OK] to proceed.



The template VISU_MC_xxx and VISU_NEW_MC_xxx are completely same except for external design.





Click the template and click [...] button at [m_Input_FB] under [Reference] and choose the right instance to be connected ("MC_Power_0" in this sample).



Set up a template for MC_MoveRelative too.

After logging in and starting PLC, inputs and outputs of function blocks can be accessed with Visualization. The left hand side is input. Boolean inputs can be set or reset like a button and numerical data can be entered in the input field. The right hand side is output. The status of Boolean outputs can be seen as lamps. The numerical data can be seen in the output field.



MEMO


Chapter 9 Trouble Shooting

9.1 Power-up Sequence





Power-up sequence is shown below figure. If your system does not work as expected, possible cause can be located in different area widely. Refer to the hints below or section 9.2 to solve.

Possible causes:

- In application program (e.g. Wrong usage of function block)
- In drives (e.g. stopped at Safe-Operational status)
- In network (e.g. DC synchronization is lost)
- In EtherCAT master (e.g. stopped with error)
- In CPU (e.g. stopped with overload error)



9.2 Trouble Shooting

	Check point	How to check	Action
1	Error indication of CPU module	Check error LED and 7-segment LED. Login with HX-CODESYS and check CPU log.	Refer to HX application manual.
2	Error indication of drives	Check error LED or error code Connect dedicated tool and check diagnostic information.	Refer to drive's instruction manual.
3	Status of EtherCAT Master	Login with HX-CODESYS and check EtherCAT master device. [No error] [Error] 	Restart EtherCAT master. [Refer to Action-1]
4	Status of drives	(1) Login with HX-CODESYS and check drives' status icon. [No error] [Error]  (2) Login with HX-CODESYS and check slaves' status [Refer to Action-2]	Check the drive's status and make the status be 'Operational'. [Refer to Action-3]
5	Status of axis	(1) Login with HX-CODESYS and check axes' status icon. [No error] [Error]  (2) Login with HX-CODESYS and check axes' status. [Refer to Action-4]	Execute MC_Reset or SMC3_ReinitDrive [Refer to Action-5]
6	Status of function blocks	Check the status of 'Error' output for all function blocks. 	Check input values. (The left figure shows error output because velocity is 0. This can be fixed by setting a value other than 0.)

<< Above error status No. 3 to 5 can be reproduced >>

No.3 Error in EtherCAT master

- The power of the first slave (connected to master) is temporary down.
- Wire breaking between the master and the first slave.

No.4 Error in the drives

- The power of the 2nd or backward slave is temporary down.
- Wire breaking between slaves.


No.5 Error in the axes

- Axis became errorstop mode while ‘Operational’ mode.

Action-1: Restart EtherCAT master

(a) Status checking and restarting EtherCAT master by function block

Add the function block IoDrvEtherCAT to your program in advance. This FB returns the status and restarts EtherCAT master.



Use the same instance as EtherCAT master device. Since this FB is implicitly declared when a master device is added, do not declare again in POU. If declaration is duplicated, CPU may stop with error.

Name		IoDrvEtherCAT		Type: FB
This FB returns the status of EtherCAT network and commands to restart or stop bus.				
Name	Type	Description		
IN	xRestart	BOOL	Rising edge: The master is restarted and all configuration parameters are reloaded.	
	xStopBus	BOOL	TRUE: Communication is stopped. No more EtherCAT telegrams are sent. On most devices, a restart is necessary after this because they are switched to error status.	
OUT	xConfigFinished	BOOL	TRUE: Transfer of all configuration parameters was completed with no errors. Communication is running on the bus.	
	xDistributedClockInSync	BOOL	If distributed clocks are used, then the PLC is synchronized with the first EtherCAT slave with the DC option activated.	
	xError	BOOL	TRUE: Error has occurred when starting the EtherCAT stack or communication with the slave is interrupted because no more messages can be received.	
	xSyncInWindow	BOOL	The output is TRUE when the <i>Sync Window Monitoring</i> option is activated and the synchronization of all slaves is within the Sync Window.	

(b) Restart EtherCAT master

Instead of the FB IoDrvEtherCAT, EtherCAT master can be restarted by manual reset operation from HX-CODESYS. Be noted that CPU stops with this reset operation. The steps to reset are; Login with HX-CODESYS and choose [Online]-[Reset warm]. Then PLC is stopped and network is initialized. Start again manually afterward.

Action-2: Check slave's status

Double click a slave device in the device tree and check [Diagnostics] in [General] tab.

The screenshot shows the configuration window for a slave device named ADVA_EC. The window is divided into several sections: General, Address, Additional, Distributed Clock, Sync0, and Sync1. The Diagnostics section is highlighted with a red box, showing the Current State as Operational. The left sidebar contains a tree view with the following items: General, Process Data, Startup Parameters, EtherCAT Parameters, EtherCAT I/O Mapping, Status, and Information. The main content area is organized into sections: Address (AutoInc Address: 0, EtherCAT Address: 1001), Additional (Enable Expert Settings, Optional), Distributed Clock (Select DC: DC for synchronization, Enable checked, Sync Unit Cycle: 4000), Sync0 (Enable Sync 0 checked, Sync Unit Cycle: x 1, Cycle Time: 4000, Shift Time: 0), and Sync1 (Enable Sync 1 unchecked, Sync Unit Cycle: x 1, Cycle Time: 4000, Shift Time: 0). The Diagnostics section shows Current State: Operational.


Just in case status is <Bad>, close the dialog and open again to update the status.

Action-3: Change the status to 'Operational'

(a) Manual operation


Login with HX-CODESYS, double click the slave device and click [Online] tab.

Change the status manually by the buttons in [State Machine]; [Init]→[Pre-Op]→[Safe-Op]→[Op].




NOTE

Activate [Enable Expert Settings] in [General] tab to show [Online] tab.




(b) Change status by function block

Add the function block ETCSlave to your program in advance. This FB commands a setting operation mode.



Use the same instance as EtherCAT slave device. Since this FB is implicitly declared when a slave device is added, do not declare again in POU. If declaration is duplicated, CPU may stop with error.

Name		ETCSlave	Type: FB
This FB returns the current operation mode and commands a setting operation mode.			
			
Name	Type	Description	
IN	xSetOperational	BOOL	Rising edge: An attempt is made to switch to the ETC_SLAVE_OPERATIONAL mode.
OUT	wState	ETC_SLAVE_STATE	Current state of the slave

ETC_SLAVE_STATE (ENUM)

Name	Value	Description
ETC_SLAVE_BOOT	3	Bootstrap (for firmware downloading)
ETC_SLAVE_INIT	1	Init
ETC_SLAVE_PREOPERATIONAL	2	Pre-Operational
ETC_SLAVE_SAVEOPERATIONAL	4	Safe-Operational
ETC_SLAVE_OPERATIONAL	8	Operational


NOTE

xSetOperational input of ETCSlave is effective only when the current mode is 'Safe-Operational'.

If the current mode is 'Init' or 'Pre-Operational', use ETCSlave.SetOpMode and set operation mode in the sequence Init→Pre-Op→Safe-Op→Op. The data type of wOpMode is ETC_SLAVE_STATE or WORD.

Tip

If [Auto restart slaves] in EtherCAT master device is enabled, communication status is changed from 'Init' to 'Operational' automatically after temporary cable disconnection.



(c) Reset operation

Instead of the FB ETCSlave, communication status can be changed to 'Operational' by manual reset operation from HX-CODESYS. Be noted that CPU stops with this reset operation. The steps to reset are; Login with HX-CODESYS and choose [Online]-[Reset warm]. Then PLC is stopped and network is initialized. Start again manually afterward


Action-4: Check the status of axis

Double click the axis in the device tree and check the status in [General] tab.

The screenshot shows the configuration interface for Drive_A. The left sidebar lists various tabs: General, Scaling/Mapping, Commissioning, SM_Drive_ETC_GenericDSP402: Parameters, SM_Drive_ETC_GenericDSP402: I/O Mapping, Status, and Information. The main area is divided into several sections:


- Axis type and limits:** Includes Modulo settings (Modulo value [u]: 360.0), Software error reaction (Deceleration [u/s²]: 0, Max. distance [u]: 0), and Dynamic limits (Velocity [u/s]: 1e3, Acceleration [u/s²]: 1e5, Deceleration [u/s²]: 1e5).
- Velocity ramp type:** Includes Trapezoid (selected), Sin², Quadratic, and Quadratic (smooth).
- Identification:** ID: 3.
- Position lag supervision:** deactivated, Lag limit [u]: 1.0.
- Online:** A table showing variable, set value, and actual value for Position [u], Velocity [u/s], Acceleration [u/s²], and Torque [Nm].
- Status window:** Shows SMC_AXIS_STATE.errorstop, Communication: error (1100), Axis Error: 0 [16#00000000], FB Error: SMC_ERROR.SMC_DI_GENERAL_COMMUNICATION_ERROR, uiDriveInterfaceError: 10, and strDriveInterfaceError: ETC device is no longer in mode operational.

In addition, MC_ReadStatus returns the current axis status as follows.




Action-5: Reset error

(a) MC_Reset



(b) If it's still 'Errorstop' status, execute SMC3_ReinitDrive to initialize the axis.



Appendix Abbreviations

CoE	CANopen over EtherCAT
DC	Distributed Clock
ENI	EtherCAT Network Information
EoE	Ethernet over EtherCAT
ESI	EtherCAT Slave Information
ESM	EtherCAT State Machine
FB	Function Block
FoE	File access over EtherCAT
FTP	File Transfer Protocol
GVL	Global Variable List
PDO	Process Data Object
POU	Program Organization Unit
SDO	Service Data Object
SoE	Servo drive over EtherCAT